

HE5J 19G217 AA
September 2016
Second Printing
Quick Reference Guide
Fusion
Litho in U.S.A.

This Quick Reference Guide is not intended to replace your vehicle *Owner's Manual* which contains more detailed information concerning the features of your vehicle, as well as important safety warnings designed to help reduce the risk of injury to you and your passengers. Please read your entire *Owner's Manual* carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of duplication. We reserve the right to change features, operation and/or functionality of any vehicle specification at any time. Your Ford dealer is the best source for the most current information. For detailed operating and safety information, please consult your *Owner's Manual*.



United States

Ford Customer Relationship Center
1-800-392-3673 (FORD)
(TDD for the hearing impaired: **1-800-232-5952**)
owner.ford.com  @FordService

Canada

Ford Customer Relationship Centre
1-800-565-3673 (FORD)
(TDD for the hearing impaired: **1-888-658-6805**)
ford.ca  @FordServiceCA

WARNING

Driving while distracted can result in loss of vehicle control, accident and injury. Ford Motor Company strongly recommends that drivers use extreme caution when using any device or feature that may take their focus off the road. Your primary responsibility is the safe operation of the vehicle. We recommend against the use of any hand-held device while driving, encourage the use of voice-operated systems when possible and that you become aware of applicable state and local laws that may affect the use of electronic devices while driving.

FUSION

Quick Reference Guide

TWO THOUSAND SEVENTEEN



COMMONLY USED VOICE COMMANDS

Press the voice button  on your steering wheel and then say:

Basic Commands

- » Main menu
- » Go back
- » Cancel
- » List of commands
- » Next page
- » Previous page
- » Help

Phone

- » Phone list of commands
- » Pair phone
- » Call <name> <on cell/ at home/ at work>
- » Dial <number>
- » Listen to message

Climate

- » Climate list of commands
- » Climate set temperature to <# degrees>

Audio

- » AM <530-1710>
- » FM <87.9-107.9>
- » CD
- » USB
- » Sirius <0-233>**
- » <Sirius channel name>**
- » Bluetooth audio
- » Help

Navigation*

- » Navigation list of commands
- » Destination <home/previous destination>
- » Find <POI/an address/ intersection>
- » Show route
- » Where am I?
- » SiriusXM Traffic and Travel Link** list of commands
 - Show <traffic/weather map/ 5 day forecast/fuel prices>
 - Help

Apps

- » List mobile apps
- » Find new apps

*available only with SYNC 3
**if equipped

Some features may not be available in your area. Refer to your Owner's Manual, visit the website or call the toll-free

number for more information. For U.S. customers: visit owner.ford.com or call **1-800-392-3673** (select Option 1 or 2 for language, then Option 3).

For Canadian customers: visit syncmyride.ca or call **1-800-565-3673** (select Option 1 or 2 for language, then Option 3).

Learn More About Your New Vehicle

Scan the country-appropriate QR code with your smartphone (make sure you have a scanner app installed) and you can access even more information about your vehicle.



owner.ford.com
(U.S.)



ford.ca
(Canada)



4-5 Instrument Panel

6-7 SYNC

8-10 SYNC 3

11-12 Comfort

13 Function

14-15 Essential Information

Left Vehicle Info Display

Using the left steering-wheel-mounted controls, press the up and down arrow buttons to scroll through and highlight the options; use the right arrow button to enter a sub-menu. MyView lets you choose what information you wish to display. Select **Change MyView** in the **Options** menu to scroll through choices.

Steering Wheel Controls

Audio Controls

Press **VOL +** or **-** to increase/decrease volume levels. Press **⏮** **⏭** to access the next or previous radio station preset, CD track or preset satellite radio channel*.

Voice Controls

Press **🗣️** to access voice recognition. Press **☎️** to answer call. Press **📞** to exit phone mode or end a call.

Service Engine Soon Light

 Lights briefly when you switch the ignition on. If it remains on or blinks after you start your vehicle, the On-Board Diagnostics (OBD-II) system has detected a problem. Drive in a moderate fashion and contact your authorized dealer as soon as possible.

Rear View Camera

Provides a video image of the area behind the vehicle. The image automatically appears in the screen when the vehicle is in reverse (R) and uses green, yellow and red guides to alert you of your proximity to objects.

Configurable Daytime Running Lamps

When you switch the feature on in the information display, daytime running lamps turn on when you are driving, the lighting control is in the autolamps position  and the headlamps are off. You can switch the Configurable Daytime Running Lamps feature **ON** or **OFF** using the information display controls. See the *Lighting* chapter in your *Owner's Manual* for complete information.

INSTRUMENT PANEL

Right Vehicle Info Display*

Use the right steering-wheel-mounted controls to access a variety of features:

» **Entertainment, Phone and Navigation*** information is also available. Refer to the *SYNC 3* chapter in your *Owner's Manual* for more information.

Electric Parking Brake

The operating switch replaces the conventional handbrake. To use, pull the switch. The brake system warning lamp lights to confirm that you applied the electric parking brake. You can release the electric parking brake manually by switching on the ignition, pressing the brake pedal and then pressing the electric parking brake switch. Refer to the *Brakes* chapter of your *Owner's Manual* for more details.

Rotary Shift Transmission

Your vehicle has an electronic transmission. The shift knob is on the center console, below the climate control system.

Putting your vehicle in gear:

- Fully press down the brake pedal.
- Turn the shift knob to select your gear.
- The gear you select lights and the instrument cluster displays the selected gear.
- Release the brake pedal and your transmission remains in the selected gear.

NOTE When entering an automatic car wash, always shift to Neutral. Push the "L" or "S" button depending on vehicle configuration, to enable Stay in Neutral Mode if you are exiting the vehicle for the car wash. Please follow the commands on the information display.

SYNC®*

SYNC is a hands-free, voice recognition system used for entertainment, information and communication. SYNC. Say the Word.

Before You Get Started

1. Set up your owner account at owner.ford.com (U.S.) or syncmyride.ca (Canada). Register and you will see which complimentary services you are eligible for.
2. SYNC uses a wireless connection called  *Bluetooth*® to communicate with your phone. Switch *Bluetooth* mode on in your phone's menu options. This lets your phone find SYNC. For more details on setting up your phone with SYNC, visit owner.ford.com (U.S.) or syncmyride.ca (Canada), or your phone manufacturer's website.

Pairing Your Cell Phone with SYNC

In order to use many of the features of SYNC, such as making a phone call or receiving a text, you must first connect or pair your phone with SYNC.

To Pair Your Cell Phone for the First Time

1. Make sure that your vehicle is in park (P), then switch your ignition and radio on.
2. Press the phone button . When the display indicates there is no phone paired, press **OK**.
3. Put your phone into *Bluetooth* discovery mode. See your phone's manual, if necessary.
4. When prompted on your phone's display, enter the six-digit PIN provided by SYNC into your phone.
5. The display indicates when the pairing is successful.

The System May Prompt You to

- » Set your phone as the *primary* or *favorite* (the primary phone receives messages and voicemail).
- » Download your phone book (a requirement to use the full set of voice commands).
- » Switch on 911 Assist®.

TIPS

- » Make sure you accept the request from SYNC to access your phone.
- » To pair subsequent phones, please refer to *Pairing Subsequent Cell Phones* in the SYNC 3 chapter of your *Owner's Manual*.
- » If you experience pairing problems, try performing a clean pairing by deleting your services from SYNC, deleting your phone pairing from SYNC, and then repeating the *Pairing Your Cell Phone with SYNC* process.

Why Do You Need a SYNC Owner Account?

A SYNC owner account provides you with the latest software updates and, if you have questions, free customer support.

NOTE Your SYNC system may offer advanced features. Visit the website or call the toll-free number for more information. See the inside front cover of this guide for details.

Using Your Cell Phone with SYNC

NOTE You must download your phone book to make phone calls with voice commands by name.

Making a Phone Call

Use SYNC to make a phone call to anyone in your phone book by pressing the voice button . When prompted, say a voice command.

For example, you could say *"Call Jake Smith at home"*. When the system confirms the number, say *"Dial"* again to initiate the call.

NOTE You can also make phone calls by pressing the voice button  and when prompted, give the voice command *"Dial"*, then verbally say the phone number.

Answering Incoming Calls

Whenever you have an incoming call, the name and number of the person calling appears in the display. Press the phone button  to answer an incoming call. You can hang up at any time by pressing and holding the phone button .

Do Not Disturb Mode

This feature blocks incoming calls and text messages and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command *"Do not disturb on"* to enable and *"Do not disturb off"* to disable.

Using SYNC to Access Digital Media

Plug in your USB media devices such as phones and MP3 players, and use SYNC to play all of your favorite music.

Using Voice Commands to Play Music

1. Plug your media player into your USB port.
2. Press the voice button . When prompted, say *"USB"*, then follow-up by saying a voice command.

SYNC® 3*



Using SYNC 3

SYNC is a hands-free, voice recognition system used for entertainment, information and communication.

Use the touchscreen to explore and interact with your vehicle. The touchscreen works the same way traditional controls, knobs and buttons do. The system provides easy interaction with your audio, climate, phone, navigation*, mobile apps and settings. Press the various corners on your touchscreen to personalize the many features and settings of your vehicle all in one place.

Create Your SYNC Owner Account

Create your account by visiting the website. Call the toll-free number for more information.

In the United States:

owner.ford.com
1-800-392-3673

In Canada:

syncmyride.ca
1-800-565-3673

Pairing Your Cell Phone with SYNC 3

Pair your phone to SYNC 3 before use. Make sure that your vehicle is in park (P) and you switch on your ignition.

1. Follow the on-screen instructions.
2. A prompt alerts you to search for the system on your phone.
3. Select your vehicle's make and model as it displays on your phone.
4. Confirm that the six-digit number appearing on your phone matches the six-digit number on the touchscreen.
5. The touchscreen indicated when the pairing is successful.
6. Your phone may prompt you to give the system permission to access information. To check your phone's compatibility, see your phone's manual or visit the website.



Phone

After pairing your phone, you can access more phone-dependent features:

- » Recent call lists.
- » Contacts: Sort alphabetically and choose a specific letter to begin viewing your entries.
- » Phone settings: Pair another phone, and set ring tones and alerts.
- » Text messages.
- » Do not disturb: Send all calls to your voice mail, and all ring tones and alerts set to silent mode.

NOTE Use the voice commands to make calls. Say "Call James at home" or "Dial 555-1212". You can use the touchscreen to place calls as well. Refer to the SYNC 3 chapter in your *Owner's Manual* for complete details.

Do Not Disturb Mode

Touch the **Do Not Disturb** button to send all calls directly to your voicemail. All ringtones and alerts are silent.



Navigation*

Press the **Navigation*** icon to set your destination. Select one of two ways to find your destination:

- » **Destination mode** lets you key in a specific address or use a variety of search methods to locate where you want to go.
- » **Map mode** shows advanced viewing of 2D city maps, 3D landmarks and 3D city models (when available).

Set a Destination

Press **Destination** on your touchscreen and then press **Search**. Enter a street address, intersection, city or a point of interest (POI).

After you choose your destination, press **Start**. The system uses a variety of screens and visible prompts to guide you to your destination.

During your route, you can press the maneuver arrow icon on the map if you want the system to repeat the previous route guidance instructions.

The navigation map shows your estimated time of arrival, remaining travel time or the distance to your destination.

Navigation Menu



While you are on your route, you can change your touchscreen view. Touch **Menu** and then select **Screen View** to select from these options:

- » Full Map.
- » **Highway Exit** displays on the right side of the touchscreen. View POI icons (restaurants, ATMs, etc.) as they pertain to each exit. You can select a POI as a waypoint, if you wish.
- » **Turn List** shows all of the available turns on your current route.
- » **Traffic List** displays SiriusXM Traffic and Travel Link* information.

Climate



Touch the **Climate** icon on the touchscreen to access climate control features, including the temperature, airflow direction, fan speed and other climate features for you and your front passenger. Say **“Climate set temperature to 72 degrees”** and SYNC 3 makes the adjustment.

You can also use the ▲ or ▼ buttons to change the temperature setting.

Audio

SYNC 3 gives you a mix of media. Press the **Audio** icon on the touchscreen and select Sources. Choose from AM, FM, SiriusXM*, CD, USB, *Bluetooth* Stereo or Apps.

Set Your Radio Presets

- » Tune to the station and then press and hold one of the memory preset buttons. The audio mutes briefly while the system saves the station, and then the audio returns.
- » Two preset banks are available for AM and three banks for FM. To access additional presets, tap the preset button. The indicator on the preset button shows which bank of presets you are currently viewing.

Use SYNC 3 to Access Digital Media

Play all of your favorite music from phones, flash drives and other devices.

Plug your device into a USB port, select **Sources** and then choose **USB**. Wait for the system to finish indexing your music to begin listening.

You can even create random playlists by using the **Shuffle** function.

Apps



Voice Control Your Smartphone Apps

The system supports the use of certain types of apps such as Pandora® or iHeartRadio® (U.S.), Spotify® or Glympse® through a USB or *Bluetooth*-enabled device. Each app gives you different on-screen options depending on the app’s content. To find new apps, use the voice command, **“Find new apps”**.

For more information, refer to the SYNC 3 chapter in your *Owner’s Manual* for details.

For support, visit the website or call the toll-free number. See the inside back cover of this guide for details.

*if equipped

Intelligent Access*

NOTE Your intelligent access transmitter must be within 3 feet (1 meter) of the vehicle for intelligent access to function properly.

This system operates the power locks on all four doors.

To unlock a door, pull the exterior door handle. Make sure not to touch the lock sensor on top of the handle. To unlock and open the luggage compartment, press the exterior release button hidden above the license plate.

To lock the doors, touch the lock sensor on top of the door handle.

The transmitter also contains a mechanical key blade to unlock the driver’s door, if necessary.

NOTE You must have a valid transmitter inside the vehicle to switch on the ignition and start the engine.

Memory Function*

Use the memory controls located on the driver’s door to program and then recall memory positions. Move the seats and mirrors to the desired positions. To program up to 2 positions, press and hold the desired pre-set button until you hear a single tone. You can now use these controls to recall the set positions.

You can also program your memory seats to your transmitter. That way, when you unlock your door with the transmitter, your memory features automatically move into your saved position. See the *Seats* chapter in your *Owner’s Manual* for more details.

*if equipped

Remote Start*

Remote start allows you to start the engine from outside your vehicle using your remote transmitter.

To start, press  and then press  twice within three seconds. Once inside, apply the brake while pressing the **START STOP** button. Shift into drive (D) and go.

To switch off the engine from outside the vehicle after using your remote start, press  once.

Auto-Start-Stop*

The system helps reduce fuel consumption by automatically shutting off and restarting the engine while stopped. If conditions are correct, Auto-Start-Stop shuts off the engine in Drive when the brake pedal is pressed and automatically restarts the engine when the brake is released or the accelerator pedal is pressed. Press the control to override this feature. It resets at each engine start. Refer to the *Unique Driving Characteristics* chapter of your *Owner’s Manual*.



Driver Seat with Easy Entry and Exit*

With the easy entry and exit feature enabled in the information display, your driver seat automatically moves rearward up to two inches (five centimeters) when you switch the ignition off. The driver seat returns to the previous position when you switch the ignition on. See the *Information Display* chapter in your *Owner's Manual* for more details.

Adaptive Cruise Control*

This system, when engaged, uses a radar and camera to scan the road ahead and detect vehicles in front of you. The system automatically brakes or accelerates to maintain set speed or follows the flow of traffic when speeds are below your set speed. In addition to selecting set speed, you may also choose between four different gap settings that control the following distance to a slower moving vehicle in front of you. The system can also bring your vehicle to a complete stop in stop-and-go traffic.

The controls for engaging and controlling the adaptive cruise control system are on the lower-left side of your steering wheel.

NOTE Please refer to the *Using Adaptive Cruise Control* section of your *Owner's Manual* for system limitations and for detailed instructions on engaging the system.

Push Button Start

Allows you to start your vehicle by fully pressing the brake pedal and the **START STOP** button. Press the button again to switch the engine off.

Tilting Head Restraints



Your vehicle's front head restraints have a tilting feature for extra comfort.

To Tilt the Head Restraint

Adjust the seatback to an upright driving or riding position. Pivot the head restraint forward toward your head to the desired position. Once it is in the forward-most position, tilting it forward once more releases it to the upright position.

NOTE Do not attempt to force the head restraint backward after tilting it. Instead, continue tilting it forward until the head restraint releases to the upright position.

Ambient Lighting*

Lights various places, such as the footwells, with a choice of colors.

Access using your touchscreen and make your adjustments:

1. Press the **Settings** icon > **Ambient Lighting**.
2. Touch the desired color.
3. Use the scroll bar to increase or decrease the intensity.

To switch off this feature, press the power button.

*if equipped

Lane Keeping System*



Notifies you to stay in your lane through the steering system and the instrument cluster display when the front camera detects an unintentional drift out of your lane is likely to occur. The system automatically detects and tracks the road lane markings using a camera mounted behind the interior rear view mirror.

Press the button located on the left steering wheel lever to switch the system on or off.

NOTE The system stores the on or off setting until you manually change it, unless the system detects a **MyKey**. Set your preferred system settings by Mode and Intensity through your information display screen. Refer to the *Information Displays* chapter in your *Owner's Manual* for more details on how to change your settings. Refer to the *Driving Aids* chapter in your *Owner's Manual* for more information on the Lane Keeping System.

Driver Alert*

Automatically monitors your driving behavior using various inputs including the front camera sensor. If the system detects that your driving alertness level reduces below a certain threshold, then the system alerts you with a tone and a message in the cluster display. Press **OK** on the steering wheel to clear the warning.

Pre-Collision Assist Warning System*

The Pre-Collision Assist system uses a radar sensor and a camera sensor to scan the road ahead to detect stationary vehicles, vehicles moving in the same direction as yours and upright pedestrians in

your driving path. The system is designed to provide an audible and visual alert, brake support, and active braking in order to help the driver reduce impact damage or avoid the crash completely. The system provides support at speeds above approximately 3 mph (5 km/h), and support for pedestrians at speeds up to 50 mph (80 km/h).

For specific details on using the system, adjusting the system alert sensitivity and familiarizing yourself with the system limitations and warnings, please refer to the section *Pre-Collision Assist* in your *Owner's Manual*.

NOTE You are responsible for controlling your vehicle at all times. The system does not relieve you of your responsibility to drive with due care and attention. Failure to take care may result in the loss of control of your vehicle, serious personal injury or death.

BLIS® (Blind Spot Information System) and Cross Traffic Alert*

BLIS aids you in detecting vehicles that may have entered into your blind spot zone. Cross traffic alert warns you of vehicles approaching from the sides when the transmission is in reverse (R). BLIS and cross traffic turn on an amber indicator light in the exterior mirror on the side of the vehicle the approaching vehicle is coming from. Refer to the *Driving Aids* chapter in your *Owner's Manual* for more information.

NOTE NEVER use BLIS or cross traffic alert as a replacement for using the interior and exterior mirrors and looking over your shoulder before changing lanes. The systems are not replacements for careful driving. Use both systems only as an assist.

*if equipped



ESSENTIAL INFORMATION

Parking Aids*

With front, rear and side sensing systems, a warning tone sounds if there is an obstacle near either bumper or near the sides of your vehicle. The warning tone increases in frequency as the object gets closer. The front sensors are active when the gearshift is in any position other than park (P) or neutral (N) and the vehicle speed is below 7 mph (12 km/h), the rear sensors activate when the vehicle is in reverse (R) and is traveling less than 3 mph (5 km/h). The side sensors are active when the transmission is in any position other than park (P).

NOTE Visibility aids do not replace the need to watch where the vehicle is moving. Refer to your *Owner's Manual* for safety information, more details and system limitations.

Active Park Assist with Park Out Assist*

The system detects an available parallel or perpendicular parking space and automatically steers your vehicle into the space (hands-free) while you control the accelerator, gearshift and brakes. The system visually and audibly guides you to park your vehicle.

- » Use the direction indicator to select which direction you want to begin searching, either to the left- or right hand side of your vehicle.
- » Then press the button once for parallel parking or twice for perpendicular parking.
- » The system displays a message and a corresponding graphic to indicate that it is searching for a parking space. Park out assist determines the clearance to the front and rear

of your vehicle and automatically steers your vehicle out of a parallel parking space (hands-free) while you control the accelerator, gearshift and brakes.

- » While your vehicle is at rest, press the button once.
- » The system displays a message requesting a direction. Use the direction indicator to select the left or right-hand side of your vehicle.

For complete information, refer to the *Parking Aids* chapter of your *Owner's Manual*.

NOTE Driving aids do not replace the need to watch where the vehicle is moving and brake when necessary. Refer to your *Owner's Manual* for safety information, more details and limitations.

*if equipped

Fuel Tank Capacity/Fuel Info

Fuel tank capacity varies on your Fusion, depending on your drive type: 16.5 gallons (62.5 liters) for front-wheel drive models and 18 gallons (68.1 liters) for all-wheel drive models. Use only UNLEADED fuel or UNLEADED fuel blended with a maximum of 15% ethanol and a minimum 87 octane rating. Do not use E85 (ethanol), diesel, fuel-methanol, leaded fuel or any other fuel because it could damage or impair the emission control system.

Refueling

Put your vehicle into park (P) and switch the ignition off. Open the fuel release door. Slowly insert the fuel filler nozzle into the fuel system, and leave the nozzle fully inserted until you stop pumping fuel. Allow about five to ten seconds after pumping fuel before removing the fuel filler nozzle. This allows residual fuel to drain back into the fuel tank and not spill onto the vehicle. Slowly remove the fuel filler nozzle.

NOTE When using a portable fuel container, slowly insert the fuel funnel (located under the luggage compartment floor covering), and pour the fuel into the funnel. When done, clean the funnel or properly dispose of it. Do not use aftermarket funnels as they do not work with the Easy Fuel system and may cause damage. You can purchase extra funnels from your authorized dealer. Refer to the *Refueling* section in the *Fuel and Refueling* chapter of your *Owner's Manual* for warnings and additional information.

Roadside Assistance

Your new Ford vehicle comes with the assurance and support of 24-hour emergency roadside assistance.

To receive roadside assistance in the United States, call **1-800-241-3673**. In Canada, call **1-800-665-2006**.

Tire Pressure Monitoring System

Your vehicle illuminates a low tire pressure warning light  in your instrument cluster when one or more of your tires are significantly under-inflated. If this happens, stop and check your tires as soon as possible, then inflate them to the proper pressure. Refer to the *Tire Pressure Monitoring* section in the *Wheels and Tires* chapter of your *Owner's Manual* for more information.

Location of Spare Tire and Tools

Your spare tire and tools are located beneath the carpeted load floor in the rear of your vehicle. The spare tire is designed for emergency use only and should be replaced as soon as possible. For complete details on changing your tire, refer to the *Changing a Road Wheel* section in the *Wheels and Tires* chapter of your *Owner's Manual*.

Towing Your Fusion

Towing your vehicle behind an RV or any other vehicle may be limited. Refer to *Towing the Vehicle on Four Wheels* in the *Towing* chapter of your *Owner's Manual*.

*if equipped

