

The logo for the Kia Soul, featuring the word "Soul" in a stylized, lowercase, red font with a slight shadow effect.

Features & Functions Guide



Delivery First
The priority that delivers more

WELCOME TO THE KIA FAMILY!

Your new Kia vehicle has been designed, engineered and manufactured to provide you with years of comfortable and dependable driving. Kia is committed to quality, innovation, safety and – above all – your satisfaction.

USING THIS FEATURES & FUNCTIONS GUIDE

The information contained in this guide is a brief overview of the operation and features of your new Kia vehicle.

This Features & Functions Guide and the specific operational and safety information it provides are not a substitute for your Owner's Manual. In the interest of your safety and that of the vehicle's occupants, and to help you avoid risks that may result in death or serious injury, Kia reminds you to carefully read the Owner's Manual in order to fully familiarize yourself with the important information and safety warnings it contains.

While Kia endeavors to ensure that the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance of or after the fact and assumes no liability in connection with such changes.

VIDEOS AND QR CODES

Kia provides a number of video resources to assist you with becoming familiar with the features and functions found in your Kia vehicle. You can access these resources by snapping the QR Codes with your mobile device using the built-in QR Code Reader or a downloaded QR Code Reader App.

After opening the QR Code Reader App on your mobile device, the app will utilize your device's camera. Center the code in the camera viewing area - With some apps, as soon as the app recognizes the code, it will launch the corresponding video.

With other apps, you will have to snap or "take a picture" of the code. The app will then launch the corresponding video.

For operation specifics, refer to the instructions that come with the QR Code Reader app. You can also view the videos by visiting the following website: www.youtube.com/KiaFeatureVideos.

QUICK TIPS

1. If you're having trouble scanning codes, check the following:
 - The code should be centered and focused in your mobile device's camera screen
 - Consider moving your device closer to or farther away from the code
 - The code should be well lit, without significant shadow
 - Avoid scanning from a significant angle
 - Confirm that the device's app supports 2D QR Code scanning
 - Try another QR Code Reader app; not all apps are created equal
2. After scanning, you may experience a "connection error" message or a "connecting" message with no subsequent response. These messages typically indicate that your device is having trouble connecting to the Internet

QR CODE

One-Click Fuel Cap Video

To view a video on your mobile device, snap this QR Code or visit the listed website. Refer to this page for more information.



www.youtube.com/KiaFeatureVideos

As you get to know your new Kia, you can explore this booklet to better understand how to operate its many features and systems. You can find the complete Table of Contents on the next two pages, but first, be sure to review the following to better understand some of your Kia's most used features:

1 Air Conditioning / Climate Control*	22-23
2 Audio Systems – UVO link Activation / UVO Assistance*	34
3 Android Auto™ / Apple CarPlay® Setup	32
4 Audio Systems – Standard Audio System*	33
5 Audio Systems – UVO link with Navigation*	36
6 Multimedia USB Port, Power Outlets & USB Charger Ports*	19
7 Bluetooth® Wireless Technology	30
8 Cruise Control (CC)*	29
9 Digital Clock	19
10 Folding Rear Seats	39
11 Manual Gear Shift*	25
12 Passenger Airbag Off Indicator	46
13 Smart Cruise Control (SCC)*	28
14 Tire Pressure Monitoring System (TPMS)	05
15 Unfastening Center Seat Belt	39
16 Windshield/Rear Wipers & Washers	29

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

www.kia.com
 Consumer Affairs - Roadside Assistance¹¹⁸:
 1-800-333-4KIA (800-333-4542)

Always check the Owner's Manual for complete operating information and safety warnings.

¹¹⁸IF EQUIPPED



VIDEOS & QR CODES Inside Front Cover

INSTRUMENT CLUSTER

Instrument Cluster Overview	03
Indicators & Warning Lights	04
Tire Pressure Monitoring System (TPMS)	05
Fuel Economy	05
Drive Mode Integrated Control System*	06

VEHICLE SETTINGS

LCD Instrument Cluster Modes*	07
Trip Modes / Trip Computer	07
User Settings Mode*	08
Sound-Reactive Mood Light*	09
Service Interval Mode*	09

ADVANCED DRIVER ASSISTANCE SYSTEMS (ADAS)

Head-Up Display (HUD)*	10
Lane Keeping Assist (LKA)*	11
Forward Collision-Avoidance Assist (FCA)*	12
Blind-Spot Collision Warning (BCW)*	13
Rear Cross-Traffic Collision-Avoidance Assist (RCCA)*	14
Rear Occupant Alert (ROA) System	14
Driver Attention Warning (DAW)*	15

DRIVER'S PANEL

Electronic Stability Control (ESC)	16
Hill-Start Assist Control (HAC)	16
Instrument Panel Dimmer	16
Engine Start/Stop Button*	17
Power Windows, Window Lock & Central Door Lock	18
Rear Door Locks	18

DRIVER'S PANEL (continued)

Power / Heated Outside Mirrors	18
Automatic Door Lock/Unlock	18

CENTER PANEL

Multimedia USB Port, Power Outlets & USB Charger Ports*	19
Digital Clock	19
Wireless Smartphone Charging System*	20
Idle, Stop & Go (ISG) System	21
Automatic Climate Control*	22
Manual Climate Control*	23
Automatic Gear Shift with Sportmatic® Shifting*	24
Dual Clutch Transmission (DCT)*	24
Manual Gear Shift*	25

STEERING WHEEL CONTROLS

Heated Steering Wheel*	26
Tilt/Telescoping Steering Wheel	26
Headlights & High Beams	27
Turn Signals & Fog Lights*	27
Smart Cruise Control (SCC)*	28
Cruise Control (CC)*	29
Windshield Wipers & Washers	29
Rear Wiper & Washer*	29
Bluetooth® Wireless Technology	30
Audio Controls	31

AUDIO SYSTEMS

Android Auto™ / Apple CarPlay® Setup	32
Standard Audio System*	33
UVO link Activation*	34
UVO Assistance*	34
Kia Access with UVO link App Download	35
Kia Access with UVO link App Features Guide	35
UVO link with Navigation*	36

SEATING

Power Adjustable Driver's Seat*	37
Seat Warmers*	37
6-Way Manual Adjustable Driver's Seat*	38
Front Seat Headrest Adjustment	38
Unfastening Center Seat Belt	39
Folding Rear Seats	39

OTHER KEY FEATURES

Map/Room Lamps	40
Sunvisor	40
Smart Key*	41
Remote Keyless Entry* (Folding Key)	42
Double-Turn Lock/Unlock All	42
Fuel Cap Open Warning Indicator*	42
Fuel Door Release Lever	42
Sunroof Operation with Sunshade*	43
Rear View Monitor (RVM)	44
Hood Release Lever and Latch	45
Liftgate Release Button	45

SAFETY FEATURES

Child-Protector Rear Door Locks	46
Occupant Detection System (ODS) / Passenger Airbag Off Indicator	46
Seat Belts	47

NORMAL MAINTENANCE - TURBO 48

NORMAL MAINTENANCE - NON-TURBO Back Cover


LEGAL DISCLAIMERS Inside Back Cover

Instrument Cluster Overview

(Type A)

- A** Tachometer
- B** Speedometer
- C** Turn Signal Indicators
- D** LCD - Gear Shift Position, Odometer, Trip Modes / Trip Computer, Exterior Temperature
- E** Engine Coolant Temperature
- F** Fuel Gauge

←  Arrow direction indicates the side of the vehicle the fuel door is located




(Type A cluster)

This illustration is for demonstration purposes only. Some indicators and warning lights may not appear in illustration. On the vehicle, they may appear in the LCD.

Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, the LCD Warning Messages and the function of all indicator and warning lights, please refer to section 2 in the Owner's Manual.

Indicators & Warning Lights



(Type B cluster)

This illustration is for demonstration purposes only. Some indicators and warning lights may not appear in illustration. On the vehicle, they may appear in the LCD.


Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, the LCD Warning Messages and the function of all indicator and warning lights, please refer to section 2 in the Owner's Manual.

- | | | | | | |
|--|---|--|--|--|--|
| | Forward Collision-Avoidance Assist*
Warning Light* | | Electronic Power Steering (EPS) Warning Light* | | Electronic Stability Control (ESC) Indicator |
| | High Beam Assist Indicator* | | Charging System Warning Light | | Electronic Stability Control (ESC) OFF Indicator |
| | High Beam Indicator Light | | Engine Oil Pressure Warning Light | | LED Headlamp Warning Light* |
| | Low Beam Indicator Light* | | Airbag Warning Light | | Immobilizer Indicator Light* |
| | Light ON Indicator Light | | Parking Brake & Brake Fluid Warning Light | | Low Fuel Level Warning Light |
| | Front Fog Light Indicator* | | Seat Belt Warning Light | | Door Ajar Warning Light* |
| | Master Warning Light | | Fuel Cap / Malfunction Indicator
(Check Engine Light) | | Cruise Indicator Light* |
| | Idle, Stop & Go (ISG) Indicator* | | Low Tire Pressure Light / Tire Pressure Monitoring
System (TPMS) Malfunction Indicator | | Lane Keeping Assistant Indicator Light* |
| | SPORT Mode Indicator Light* | | Electronic Brakeforce Distribution (EBD)
System Warning Light (Two separate indicators on
Instrument Cluster lit at same time) | | Low Windshield Washer Fluid |
| | ECO Mode Indicator Light* | | Electronic Brakeforce Distribution (EBD)
System Warning Light (Two separate indicators on
Instrument Cluster lit at same time) | | Liftgate Open Warning Light* |

Tire Pressure Monitoring System (TPMS)^{†24}

 The indicator  functions as both Low Tire Pressure Light and TPMS Malfunction Indicator.

The TPMS indicator illuminates if it detects one or more tires is significantly under inflated, the vehicle has a spare tire installed without TPMS or the outside temperature becomes significantly lower.



- The LCD screen in the instrument cluster will display the Low Tire Pressure indicator  showing which tire(s) is underinflated
- Inflate tire(s) to specifications using an accurate tire pressure gauge to turn off Low Tire Pressure Light . See front driver's door jamb for PSI specification
- When there is a problem with the TPMS, the TPMS Malfunction Indicator  will blink for approximately one minute and then illuminate – See dealer for service

QUICK TIPS

- Even with TPMS, tire pressure should be checked manually at least once a month. Only adjust tire pressure on “cold tires” that have been sitting for at least 20 minutes tires and are not hot in temperature from direct sunlight or heat
- For proper maintenance and optimal fuel economy, maintain recommended tire inflation pressures and stay within the load limits and weight distribution recommended for your vehicle
- In winter or cold weather, the TPMS light may illuminate if the tire pressure was adjusted to the recommended tire inflation pressure during warm weather

REMINDERS:

- Check the recommended tire pressure label located on the left side of driver's door jamb, visible when the door is opened
- Consult your dealer for service if Low Tire Pressure Light remains illuminated after inflating your tire(s)
- Personal electronic devices (such as laptops, wireless chargers, remote start systems, etc.) may interfere with the TPMS system, which may cause the Malfunction Warning Indicator (Check Engine Light) to illuminate

Refer to section 6 in the Owner's Manual for more information.

Fuel Economy

There are several factors that contribute to your vehicle's fuel economy, such as maintenance of your vehicle, driving style, environmental conditions, vehicle weight and vehicle aerodynamics. Below are some tips on how to help improve fuel economy:

- Keep your vehicle in good condition with regular maintenance
- Don't let the engine idle longer than necessary
- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Travel lightly, without carrying unnecessary weight in your vehicle
- Avoid placing large or heavy items on roof racks
- Avoid hilly, winding or poorly maintained roads

Refer to section 4 in the Owner's Manual for more information or snap the QR Code above to view a video.

Images are for illustrative purposes only. Actual image or feature may vary.

QR CODE

To view these videos on your mobile device, snap these QR Codes or visit the listed website.

Refer to the inside cover for more information.

Tire Pressure Monitoring System



www.youtube.com/KiaFeatureVideos

Fuel Economy Video



www.youtube.com/KiaFeatureVideos

Drive Mode Integrated Control System*

The Drive Mode may be selected based on the driver's preferences and road conditions.

To cycle through the different Drive Modes **A**, press the DRIVE MODE button **B**. The instrument cluster will display SPORT when selected. When in NORMAL mode, it will not display in the instrument cluster.

QUICK TIPS


- In SPORT mode, when engine is turned off, the system will default to NORMAL mode and SPORT mode will need to be selected again when the vehicle restarts.
- To help improve your fuel economy:
 - Drive at a moderate speed, accelerating smoothly and at a moderate rate
 - Keep tires inflated to the recommended pressure
 - Be sure the wheels are properly aligned

REMINDERS:

- The system is turned ON and in NORMAL mode when ignition is in the ON position
- Steering effort may be slightly increased in Sport mode
- When SPORT mode is selected, fuel economy may decrease

For illustrative purposes only. Your actual display, buttons and/or features may vary.

Refer to section 5 in the Owner's Manual for more information.



(Button located in center console below gear shift)

QR CODE

Drive Mode Integrated Control System Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

LCD Instrument Cluster Modes*

Press the Mode/Select button **A** to cycle through different LCD Instrument Cluster Modes:



Trip Computer Mode: Displays driving information for fuel economy, accumulated info, etc.



Turn-by-Turn Mode*: Displays the route guidance and destination info



Driving Assist: Displays the Lane Safety*, Driver Attention Warning*, Smart Cruise Control* and TPMS info



User Settings Mode: Change settings of the Head-Up Display*, doors, lights, sound, driving assistance*, convenience, service interval and other features



Master Warning Mode: Displays warning messages related to the vehicle when one or more systems is not operating normally

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Refer to section 4 in the Owner's Manual for more information.

Trip Modes / Trip Computer


The Trip Computer is a driver information system that displays information related to driving on the display when the ignition switch or the Engine Start/Stop button* is in the ON position.

To cycle through the LCD Instrument Cluster modes, press the Mode/Select button **A**.

When in the Trip Computer mode , press the OK/Move/Select/Reset button **B** up or down to cycle through the screens. When displaying the Tripmeter, press and hold the OK button **B** to reset the Tripmeter to zero.

REMINDERS:


- Appearance of Tripmeter display may differ as equipped
- All stored driving information (except Odometer and Range) is reset if the battery is disconnected



(For Type B cluster; Buttons located on steering wheel)

Your vehicle's steering wheel buttons may differ from those in the illustrations.

Refer to section 4 in the Owner's Manual for more information.



(Type B Cluster)

User Settings Mode*

To enter the User Settings mode in the LCD Instrument Cluster Modes, press the Mode/Select button **A** when the vehicle is at a standstill and with the Engine Start/Stop* button in the ON position and select User Settings .

You can navigate the selections on the display by pressing the Move/Reset button **B**, and then selecting the item by pressing the Mode/Select button **A**.

Head-Up Display*:

- Display Height
- Rotation
- Brightness
- Contents Selection
- Speedometer Size
- Speedometer Color

Driver Assistance*:

- Smart Cruise Control Response
- Driver Attention Warning
- Warning Timing
- Warning Volume
- Forward Safety
- Lane Safety
- Blind-Spot Safety

Door/Liftgate:

- Automatically Lock
- Automatically Unlock

Lights:

- One-Touch Turn Signal
- Headlamp Delay

Sound:

- Welcome Sound

Convenience*:

- Welcome Mirror
- Wipers/Lights Display
- Auto Rear Wiper
- Gear Position Pop-Up
- Icy-Road Warning

Service Interval:

- Enable Service Interval
- Adjust Interval
- Reset


Other Features*:

- Fuel Economy Auto Reset
- Fuel Economy Unit
- Temperature Unit
- Tire Pressure Unit
- Torque Unit
- Turbo Boost Pressure Unit

Reset:

- Reset menus to factory settings (except language & service interval)

Refer to section 4 in the Owner's Manual for more information.



(For Type B cluster; Buttons located on steering wheel)

Sound-Reactive Mood Light*

The vehicle's speaker lights can be customized, including setting the lights to change according to the mood of the music playing.


To change the settings, go to All Menus in the audio head unit. Select Sound Mood Lamp and adjust the different settings.

QUICK TIP

To reset back to the default settings, press the Reset button on the audio head unit screen.

REMINDERS:

- Mood Lights cannot be changed while vehicle is moving
- Park vehicle in a safe location before changing the settings
- When any door is opened, the lighting turns off



Refer to the Car Multimedia System User's Manual for more information.

Service Interval Mode*

To enter Service Interval Mode, press the Mode/Select button **A** and select User Settings ⚙️, then scroll to Service Interval by pressing Move/Reset button **B**. Press the Mode/Select button **A** to enter. System will display number of miles remaining until next service is due, and type of service.

When service is required, the following will be displayed: **Service Required**.

To reset the Service Interval Mode system, press and hold the Move/Reset button **B** for more than 1 second.


To turn **Service In** OFF, go to User Settings.

Service Interval Setting

To set the service interval when in User Settings mode:

- Press the Move/Reset button **B** and scroll to Service Interval. Press the Mode/Select button **A** to enter
- Press the Move/Reset button **B** and toggle to ON, then press the Move/Select button **A**. Then press the Move/Reset button **B** to scroll and select the desired miles or months for your next service
- Press the Mode/Select button **A** to enter

Refer to section 4 in the Owner's Manual for more information. For illustrative purposes only. Your actual display, buttons and/or features may vary.



(For Type B cluster; Buttons located on steering wheel)



(Instrument cluster LCD screen shown)

QR CODE

To view these videos on your mobile device, snap these QR Codes or visit the listed website.

Refer to the inside cover for more information.

LCD Display Video



LCD Display: Maintenance Video



www.youtube.com/KiaFeatureVideos

Head-Up Display (HUD)*†11

The Head-Up Display (HUD) is a semi-transparent display that projects a snippet of information from the instrument cluster and navigation system* onto the popup glass. To turn HUD ON or OFF, and press the HUD button **A**.

The HUD displays:

- Turn By Turn (TBT) navigation information
- Lane Safety information
- Road signs
- Blind-Spot Safety information
- Speedometer
- Warning lights (low fuel)
- Cruise setting speed
- AV mode information
- Smart Cruise Control information*

Head-Up Display (HUD) User Settings


Drivers can adjust the HUD settings from the LCD Instrument Cluster modes in User Settings.

HUD settings include:


- Display Height: Adjust the height of the HUD image on the windshield glass
- Rotation: Adjust the degree of HUD rotation
- Brightness: Adjust the intensity of the HUD brightness
- Contents Selection: Activate or deactivate HUD content (Audio/video, Driving Assist, Lane Safety and Blind-Spot, Turn-by-Turn and Traffic Safety info)
- Speedometer Size: Choose the size of the HUD speedometer (Small, Medium, Large)
- Speedometer Color: Choose the color of the HUD speedometer (White, Orange, Green)

REMINDERS:

- The HUD image on the windshield glass may not be visible when:
 - The driver has poor sitting posture
 - The driver is wearing polarized sunglasses
 - There is an object covering the HUD
 - Driving on a wet road
 - Excessive lighting inside or outside the vehicle
- If Turn By Turn (TBT) navigation information is selected as HUD content, TBT information will not be displayed on the LCD
- Modifications made to the windshield, such as tinting or other aftermarket treatments, could affect the HUD. When replacing the front windshield glass of vehicles equipped with the HUD, owners must replace it with windshield glass designed for HUD operation. Otherwise, duplicated images may be displayed on the windshield glass



(Button located in panel to the left of steering wheel)



For illustrative purposes only. Your actual display may vary.

The Head-Up Display is a supplemental system. Do not solely rely on the system, always drive safely, and pay attention to the driving conditions on the road.

Refer to section 4 in the Owner's Manual for more information.

Lane Keeping Assist (LKA)*†6

With the Engine Start/Stop button in the ON position, press the Lane Safety button **A** to turn the system ON. The instrument cluster indicator  will illuminate white. It will remain white when vehicle is traveling less than 40 mph and the system does not detect the lane markers. When LKA detects the lane markers and can assist the steering, the LKA icon will illuminate green.

If LKA detects that you are moving outside of your lane, the system may give an audible warning and display a Lane Departure Warning alert on the instrument cluster. If the vehicle continues to move outside of the lane, LKA can provide steering inputs, trying to prevent the vehicle from moving outside its lane.

LKA is the operating mode by default when the Lane Safety button is depressed to ON. To switch between LKA modes (Active LKA, LKA and Lane Departure Warning), go to Vehicle Settings* in the audio control unit or the User Settings* in the Instrument Cluster.

All systems will operate under the following conditions:


- The vehicle exceeds approximately 40 mph
- The vehicle is between the lane markers
- LKA recognizes the lane the vehicle is traveling in

REMINDERS:

- When the vehicle changes lanes without a turn signal, LKA may sound an audible warning. The warning sound can be adjusted in the User Settings.
- LKA/LDW will not issue a warning if the turn signal or hazard signal is activated
- LKA/LDW will return to its previous state when the ignition is cycled

Lane Keeping Assist is not a substitute for safe and proper driving. Always drive safely and use caution. LKA may not always alert the driver if the vehicle is driven outside of its lane.*

Refer to section 5 in the Owner's Manual for more information.



When the front view camera detects the lanes traveling in, the indicators are illuminated



When the front view camera does not detect the lanes traveling in, the indicator will not illuminate



When the front view camera detects the vehicle moving outside of the lane the vehicle's traveling in, a yellow indicator will illuminate, either on the left or right lane



QR CODE

Lane Keeping Assist Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

STORY

Forward Collision-Avoidance Assist (FCA)*†6

FCA is designed to detect and monitor a vehicle ahead or detect a pedestrian in the roadway through front view camera recognition and front radar signals to warn the driver that a collision is imminent, and if necessary, apply emergency braking. Initially, FCA provides Forward Collision Warning when it detects a potential collision with a vehicle in front, emitting an audible warning and visual alert on the Instrument Cluster LCD **A**. Adjust the Warning Time (Early, Normal, Late) in the User Settings menu on the Instrument Cluster display. FCA is ON by default and can be turned OFF in the User Settings, selecting Driving Assist, then Forward Collision-Avoidance Assist.

If the system detects that the collision risk has increased, the FCA automatically applies the brakes to reduce your speed, potentially helping to avoid or reduce the effects of a possible collision.

FCA will become active when the:

- Engine Start/Stop button is ON
- Vehicle is traveling more than 6 mph
- Electronic Stability Control (ESC) is ON

REMINDERS:

- FCA will be activated by default when vehicle power is cycled on, even when previous setting is off
- If FCA is operating and the ESC (Electronic Stability Control) is turned off, FCA is automatically turned off
- When FCA is off, FCA warning indicator is on in the instrument cluster
- The warning sound can be adjusted in the User Settings

Forward Collision-Avoidance Assist is not a substitute for safe and proper driving. Always drive safely and use caution. FCA may not always alert the driver when the vehicle is approaching another vehicle.*

For illustrative purposes only. Your actual display, buttons and/or features may vary.

Refer to section 5 in the Owner's Manual for more information.



QR CODE

Forward Collision-Avoidance Assist (FCA) Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

Blind-Spot Collision Warning (BCW)*†‡

BCW uses rear corner radar sensors in the rear bumper to monitor and warn the driver, in certain situations, if it detects an approaching vehicle in the driver's blind spot area. The BCW System is ON when the button **A** is pressed – the button light will illuminate. The outside rearview mirror warning lights will also illuminate for 3 seconds.

To activate BCW, go to User Settings by pressing the Mode button on the Steering Wheel. Select Driver Assistance > Blind-Spot Safety and then press the OK button. Select Warning Only or Off.



The system will become active when the vehicle is traveling more than 20 mph and will warn the driver if another vehicle is detected by the radar sensor.

1st-stage warning: When another vehicle is detected within the blind-spot area **B**, or when a vehicle is detected closing at high speed, a yellow indicator will illuminate on the outside rearview mirrors.

2nd-stage warning: When 1st-stage warning is on and the driver activates a turn signal, a flashing yellow indicator will illuminate on the outside rearview mirrors and the system will sound a warning.

REMINDERS:

- BCW will not issue a warning if the vehicle speed is 6 mph or more than the speed of the surrounding vehicles
- When BCW is ON and the ignition is cycled, BCW returns to its previous state
- The BCW warning sound can be adjusted in User Settings
- See the Owner's Manual for more detailed information, limitations and conditions



BCW is a supplemental system. Do not solely rely on this system and always pay attention to the road and its conditions.

Images are for illustrative purposes only and may not reflect actual operation.

Refer to section 5 in the Owner's Manual for more information.

QR CODE

Blind-Spot Collision Warning Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

Rear Cross-Traffic Collision-Avoidance Assist (RCCA)*†6


If RCCA detects approaching vehicles from the rear left or rear right side of the vehicle **A**, the system will sound an audible warning, the warning indicators on the outside rearview mirror will illuminate and a message will appear on the Instrument Cluster LCD **B**. RCCA may activate the Electronic Stability Control (ESC) to help avoid an imminent collision. RCCA may temporarily apply braking power when an approaching vehicle is detected within a certain distance next to or behind the vehicle.

RCCA is designed to operate under the following conditions:

- When the gear shift is in Reverse
- When the vehicle is moving slower than 6 mph

REMINDERS:

- The RCCA Warning sound can be adjusted in the User Settings* or the Vehicle Settings* on the audio head unit
- When vehicle power is cycled, RCCA will remain in the previous state
- RCCA can be turned OFF/ON in User Settings
- RCCA will show a warning if the approaching vehicle speed is between 2.5-22 mph within sensing range. See owner's manual for other conditions
- RCCA is a supplemental system. Do not solely rely on this system and always pay attention to the road and its conditions



Images are for illustrative purposes only and may not reflect actual operation.

Refer to section 5 in the Owner's Manual for more information.

Rear Occupant Alert (ROA) System

The Rear Occupant Alert (ROA) system can help alert the driver when a rear passenger may be left in the vehicle. The alert will be a message on the Instrument Cluster stating to "Check rear seats" **C** and a chime will sound.

To turn the system OFF or ON, go to Vehicle Settings*, select Convenience, then Rear Occupant Alert and check/uncheck the box to enable/disable by pressing the OK button on the Steering Wheel.



REMINER: Always be sure to check the passenger areas before leaving the vehicle.

The Rear Occupant Alert system is not a substitute for one's attention. Always check the vehicle's interior before exiting.

Image is for illustrative purposes only and may not reflect actual feature or operation.

Refer to section 4 in the Owner's Manual for more information.

Driver Attention Warning (DAW)*†6

DAW is designed to alert the driver if it detects certain inattentive driving and, in certain situations, can give a warning signal to take a break from driving.

DAW is set to OFF by default. To turn DAW ON, turn the ignition on and then select User Settings in the LCD Display on the Instrument Cluster. Then go to Driver Assistance and select Driver Attention Warning. Set DAW to Normal or High Sensitivity.

Driver Attention Warning modes:

OFF: The Driver Attention Warning system is deactivated **A**

Normal Sensitivity: Driver Attention Warning warns the driver of inattentive driving practices

High Sensitivity: Driver Attention Warning warns the driver of inattentive driving practices faster than Normal mode

If DAW System is activated, DAW information will appear on the LCD Display **B** when you select the ASSIST mode .

A message, “Consider taking a break,” appears on the LCD display and a warning sounds to suggest the driver to take a break when the driver’s attention level is below one bar **C**.



REMINDERS:

- The setup of DAW will be maintained, as selected, when the ignition is cycled
- When activated, DAW does not display “Consider taking a break” message when the total trip driving time is less than 10 minutes
- The DAW System will enter a standby mode if the front-view camera does not detect the lanes and/or the driving speed remains under 40 mph

Driver Attention Warning is not a substitute for safe driving and may not detect all instances of inattentive driving practices. Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.

Refer to section 5 in the Owner’s Manual for more information


Electronic Stability Control (ESC)*†7

The ESC system is designed to help stabilize the vehicle during certain cornering maneuvers. It is a good idea to keep the ESC turned ON for daily driving whenever possible.

Press ESC button **A** to turn ESC OFF/ON.

REMINDERS:

- ESC is ON by default at vehicle startup. When ignition is cycled, ESC will turn ON again
- The ESC Indicator Light in the instrument cluster will be lit momentarily whenever the ESC is active



Refer to section 5 in the Owner's Manual for more information.

Hill-Start Assist Control (HAC)†7

HAC is designed to prevent the vehicle from rolling backward when accelerating from a stop while on a steep incline. The HAC automatically activates whether the ESC is OFF or ON, but does NOT activate when the ESC has malfunctioned.

QUICK TIPS

- HAC provides a two-second delay before the vehicle may start rolling backwards
- When HAC is active (e.g., accelerating from a stop on an incline), you may notice that the brakes will momentarily remain engaged after you depress the accelerator


REMINDERS:

- The HAC does not operate when the gear shift is in the P (Park) or the N (Neutral) position
- In the event of HAC system malfunction, see an Authorized Kia Dealer for service
- HAC does not replace the need to apply brakes while the vehicle is stopped on an incline


Refer to section 5 in the Owner's Manual for more information.

Instrument Panel Dimmer

With parking lights / headlights ON, press the button **B** + or – to adjust display brightness of the instrument panel illumination.



(Button located in panel to the left of steering wheel)



REMINDERS:

- Door Mood Lamp is a fixed brightness and cannot be adjusted (not to be confused with Advanced Mood Lighting Speaker)
- If the brightness reaches to the maximum or minimum level, an alarm will sound

Refer to section 4 in the Owner's Manual for more information.

Engine Start/Stop Button*†‡

To start the engine:

1. Depress the brake pedal
2. Press the ENGINE START/STOP button while gear shift is in P (Park) (light **A** will not illuminate when starting)

To turn the engine OFF – Press the ENGINE START/STOP button again.

To use the ENGINE START/STOP button, the Smart Key fob must be in the vehicle.

QUICK TIPS

To use electrical accessories:

ACC position

- When in the OFF position (no light) and without depressing the brake pedal, press the ENGINE START/STOP button once (amber light **A**)

On position


- When already in the ACC position (amber light **A**) and without depressing the brake pedal, press the ENGINE START/STOP button again (reddish-orange light **A**)
- When in the OFF position (no light) and without depressing the brake pedal, press the ENGINE START/STOP button twice (reddish-orange light **A**)

Keeping the vehicle in ACC or the ON position without engine running may discharge the vehicle's battery.

REMINDERS:

- In an emergency situation while the vehicle is in motion, you are able to turn the engine off and to the ACC position by pressing the ENGINE START/STOP button for more than 2 seconds or 3 times successively within 3 seconds
- If Smart Key fob battery is dead, with the lock button facing the ENGINE START/STOP button, hold the fob up against the ENGINE START/STOP button and press

Refer to section 5 in the Owner's Manual for more information.



(Button located above Gear Shift)

QR CODE

To view videos on your mobile device, snap these QR Codes or visit the listed website. Refer to the inside cover for more information.

Engine Start/Stop Button & Smart Key Video



Kia Key Fob Video



www.youtube.com/KiaFeatureVideos

Power Windows, Window Lock & Central Door Lock

A Pull/Press to operate Driver's and Front Passenger's window Auto Up/Down*


QUICK TIP

Press button again to stop Auto Up/Down function.

B Press to Unlock/Lock All Doors

C Press to disable Rear Passenger Windows

REMINDER: When button **C** is pressed, window controls for the Rear Passenger Windows are disabled.



QUICK TIPS

While driving with the rear windows down or with the sunroof* in an open or partially open position, a wind buffeting or pulsation noise may be heard. This noise is a normal occurrence and can be reduced or eliminated by the following:

- If the noise occurs with one or both of the rear windows down, partially lower both front windows approximately 1 inch
- If the noise occurs with the sunroof open, slightly reduce the size of the sunroof opening

Refer to section 4 in the Owner's Manual for more information.

Rear Door Locks

If the inner door handle is pulled once when the door is locked, the door will unlock. If the inner door handle is pulled once more, the door will open.

Refer to section 4 in the Owner's Manual for more information.

Power/Heated Outside Mirrors*

Use mirrors heaters to defrost/defog mirrors. Mirror heaters are controlled with the Rear Defroster.

Toggle switch **D** left or right to select mirror. Then press arrows **E** to adjust mirror position.

Refer to section 4 in the Owner's Manual for more information.

Automatic Door Lock/Unlock

Auto Door Lock/Unlock will engage when the gear shift is moved into or out of the P (Park) position. Refer to the User Settings in the LCD Instrument Cluster modes on how to turn Auto Door Lock/Unlock ON/OFF.


Refer to section 4 in the Owner's Manual for more information.

Multimedia USB Port, Power Outlets & USB Charger Ports*

Multimedia USB Port A: Use the Multimedia USB Port to connect USB audio and smartphone devices.

USB Charger Port B: Use the USB Charger Port on the right to charge devices. One USB Charger Port is located in the back of the center console*.

Power Outlets C: Use the power outlets for mobile phones and other devices designed to operate on a 12V (180W max) power outlet.



(Ports and power outlets located on lower part of Center Panel; If equipped, an additional Power Outlet is located in the rear cargo area of the vehicle)

QUICK TIPS

- The power outlets are inactive when ignition is in the OFF position
- The USB data port (Multimedia USB Port) **A** is located next to the Power Outlets. USB Charger Ports do not support data transfer
- The power outlets are inactive when ignition is in the OFF position

REMINDERS:

- Kia recommends that you only use USB cables made by your device's manufacturer. Third-party USB cables may cause damage to your device
- Using the Power Outlet (accessory plug) for prolonged period time with the Engine Start/ Stop button in the ACC position (Engine OFF) could cause the battery to discharge.
- The Multimedia USB Port **A** in the center panel charges slower than the USB Charger Ports **B** throughout the vehicle

Refer to section 4 in the Owner's Manual for more information.

Digital Clock

Press the SETUP key, then the DATE/TIME button to display the Clock Settings screen. Then use the onscreen buttons to navigate through setup and return \Rightarrow to exit.

QUICK TIPS

- When needed, Daylight Savings must be enabled in the Clock Settings screen (UVO link with Navigation*)
- To access manual date and time setting, turn GPS Time OFF in the Clock Settings (UVO link with Navigation*)

For more information, refer to the Car Infotainment System Quick Reference Guide.

Wireless Smartphone Charging System*


1. Enable Wireless Charging in the Instrument Cluster's User Settings
2. Place a compatible smartphone on the center of the charging pad.
3. Indicator light **A** may change to amber once wireless charging begins.
4. Once charging is complete, the amber light may change to green.

QUICK TIPS

- For wireless charging to occur, all doors (excluding rear hatch) must be closed & the Smart Key Fob must be detected inside the vehicle
- For best results, place smartphone on the center of the charging pad
- If wireless charging does not work, move smartphone around the pad until the charging indicator turns amber. Avoid placing other metal items in the bin while charging as to not impede the charging area

REMINDERS:

- The smartphone must be a compatible phone with Qi function available
- Avoid placing other metal items in the bin while charging as to not impede the charging area
- This vehicle is equipped with wireless charging technology which allows for a device to be charged using inductive charging; however, device compatibility varies. See your Owner's Manual for more detailed information
- Inductive charging systems are less efficient than conventional charging through cable. As a result, higher device operating temperatures may be experienced during use
- Charging Performance – Your device's position on the wireless charging system can affect charging performance. Other factors that may affect the charging rate include foreign objects, such as coins or pens, and phone case thickness
- If driver door is opened, charging will be disabled



(Located in front of Gear Shift)

QR CODE

Wireless Charging Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

Idle, Stop & Go (ISG) System*

The ISG system is designed to help reduce fuel consumption by automatically shutting down the engine when the vehicle is at a standstill.

When the ISG system is ON, the vehicle is at a standstill, and all preconditions have been met, the engine will stop and the green AUTO STOP indicator (A) on the instrument cluster will illuminate.

The engine will restart when the brake pedal is released or the shift lever is moved from D (Drive) to the R (Reverse) position or to Manual Shift mode*. When engine restarts, the green AUTO STOP indicator on the instrument cluster will turn off.

To deactivate the ISG System, press the ISG OFF button (A) (LED lit). If you press again, the system will be activated.


QUICK TIPS

- The ISG system is disabled when:
 - A seat belt is unfastened
 - The hood or a door is opened
 - Battery condition is poor
 - The front or rear defroster is turned on
 - Engine coolant temperature is low
 - The outside ambient temperature is too low/high
 - Emission control devices activate
 - The vehicle is on a steep slope

REMINDERS:

- When the AUTO STOP indicator illuminates solid yellow, the system is activated without faults, but will not operate until all the conditions are met
- ISG is active by default at vehicle start-up. When ignition is cycled, ISG will turn ON again
- Under certain conditions, the engine will restart automatically even if the brake pedal is still depressed
- If the AUTO STOP indicator (A) is continuously blinking yellow and the ISG button LED is on, please contact an authorized Kia dealer

For more information on Idle, Stop and Go System, refer to section 2 in the Owner's Manual or contact your local dealership.



QR CODE

Idle, Stop & Go Video


To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

Automatic Climate Control* (Type B)



Air Flow Modes

To select Air Flow Modes, press the mode selection buttons:

- Face-Level
- Face/Floor-Level
- Floor-Level
- Floor/Defrost-Level

REMINDERS:

- Cold or warm ambient air may flow in through vents if Recirculated Air button is not pressed ON (LED lit)
- Pressing any button during AUTO operation will deactivate the AUTO function and switch to manual mode, except for Temperature Control
- When in AUTO mode, Air Flow Mode and Fan Speed do not display on the Climate Control Display

Climate Control Auto Function:

1. Press **AUTO** to select Full Auto Operation - The Auto setting automatically controls the airflow modes, fan speeds, air intake and air conditioning according to the temperature setting selected
2. Set desired **Temperature**
3. Press **SYNC** to sync the left and right temperature control

Defrost Outside Windshield:

1. Set **Fan Speed** to the highest position
2. Set **Temperature** to **Hot**
3. Press the **Front Defrost button**

Defog Inside Windshield:

1. Set **Fan Speed** to highest position
2. Set **Temperature** to highest position
3. Press the **Front Defrost button**

Auto Defogging System (ADS):

Auto defogging is designed to reduce the fogging up of the inside of the windshield by automatically sensing the moisture of the inside of the windshield. The system will automatically change to defrost mode when needed.

Auto Defogging is set ON by default. To cancel Auto Defogging, press the Front Defrost button for three seconds, when the ignition is in on (ADS OFF icon will illuminate). To turn Auto Defogging on again, press the Front Defrost button for three seconds.

QR CODE

Auto Defogging System (ADS) Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.




www.youtube.com/KiaFeatureVideos

QUICK TIPS

- Continuous use of the climate control system in the recirculated air position may allow humidity to increase inside the vehicle which may fog the glass and obscure visibility
- Keep inside glass as clean as possible to reduce window fogging
- Defrost mode activates A/C and opens Fresh Air Vent
- During Auto Operation the A/C indicator will NOT illuminate. The fan speed, air intake, airflow and air conditioning may automatically engage at any time to reach desired temperature and reduce humidity

Your Automatic Climate Control system may differ from those in the illustrations. See your Owner's Manual for more details.

Manual Climate Control*



Defrost Outside Windshield:

1. Set **Fan Speed** to the highest position
2. Set **Temperature** to **Hot**
3. Rotate knob to the **Front Defroster** mode 

QUICK TIPS

- Defrost Mode  activates A/C and opens Fresh Air Vent
- MAX A/C Mode automatically engages Recirculated Air
- Keep inside glass as clean as possible to reduce window fogging

Defog Inside Windshield:

1. Set **Fan Speed** to desired position
2. Set desired **Temperature**
3. Rotate knob to the desired **Front Defrost** mode 

REMINDERS:

- Continuous use of the climate control system in the recirculated air position may allow humidity to increase inside the vehicle which may fog the glass and obscure visibility
- Warm air may flow in through vents if Recirculated Air button is not pressed ON (LED lit)

Your Manual Climate Control system may differ from those in the illustrations. See your Owner's Manual for more details.

Air Flow Modes

To select Air Flow Modes, press the Mode selection buttons:

-  Face-Level
-  Face/Floor-Level
-  Floor-Level
-  Floor/Defrost-Level
-  Defrost-Level

Automatic Gear Shift with Sportmatic® Shifting*†20



P: Park
R: Reverse
N: Neutral
D: Drive

[+]: Manual Mode Upshift
[-]: Manual Mode Downshift

Manual Mode:

To enter Manual mode, move shift lever from D to left gate **A**

To shift while in Manual mode, move shift lever up [+] to upshift or down [-] to downshift.



QUICK TIPS

- Press brake pedal and depress release button to move gear shift from N to P, N to R or from P to any gear
- Manual Mode downshifts are made automatically when the vehicle slows down. When the vehicle stops, 1st gear is automatically selected

QR CODE

Sportmatic® Shifting Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

Dual Clutch Transmission (DCT)*

Some Kia vehicles are equipped with Dual Clutch Transmission (DCT) for both automatic and manual transmissions.

The following are unique driving tips of the Dual Clutch Transmission:

- To hold the vehicle stationary on an incline, the service brake or parking brake **MUST** be used or the gear shift **MUST** be in the (P) Park position. If the vehicle is held stationary by applying the accelerator pedal on a slope, the clutch/transmission may overheat, resulting in damage
- Avoid aggressive launches on steep grades as this may result in an overheated clutch and transmission
- A slight time lag may be experienced at takeoff from standstill during aggressive acceleration maneuvers

If the clutch is overheating an amber-colored warning light  will be displayed on the instrument cluster. **Should this condition occur, pull over and place the vehicle in Park and idle the engine.**

Refer to the Owner's Manual for additional information on DCT operation or call Kia Consumer Affairs for additional information.






Manual Gear Shift*

Starting the Engine

1. Pull up to apply Parking Brake **A**
2. Fully depress Clutch and Brake Pedals to floor **B**
3. Shift into Neutral **C**
4. Turn Ignition to START

Shifting into Reverse

1. Fully depress Clutch and Brake Pedals to floor **B**
2. Shift into Neutral **C**
3. Press Gearshift Button **D**
4. Shift into Reverse **E**




QUICK TIP

When shifting into gears 1-6, the Shift Lever can be moved without pulling the Shift Lever Ring.

Refer to section 5 in the Owner's Manual for more information.

Heated Steering Wheel*

Press button **A** to turn ON/OFF steering wheel heater while the Engine Start/Stop Button is in the ON position. The steering wheel heater will turn off automatically in 30 minutes, or when button is pressed again to deactivate.



(Button located to the right of gearshift)

QUICK TIP

If ignition is turned OFF, then ON again, within 30 minutes of the steering wheel heater being turned on, the system will automatically be set ON again.


REMINDER: If the steering wheel becomes too warm, turn the system off. The heated steering wheel may cause burns even at low temperatures, especially if used for long periods of time.

Refer to section 5 in the Owner's Manual for more information.

Tilt/Telescoping Steering Wheel†23

To adjust the Steering Wheel, push down the lock-release lever **B** and adjust to the desired angle **C** and distance **D**.

When finished, pull up the lock-release lever **B** to lock Steering Wheel in place.



QUICK TIPS

It may be helpful to pull/push bottom of the steering wheel towards/away from you to adjust desired distance prior to adjusting the angle.

Refer to section 5 in the Owner's Manual for more information.

Headlights & High Beams


To operate:

- Rotate lever switch to change the Headlight function
- Push lever to turn High Beams ON
- Pull lever to flash Headlights / High Beams

AUTO Light position – When the light switch is in the AUTO light position, the tail lights and headlights will turn ON/OFF automatically, depending on the amount of light outside the vehicle.

High Beam Assist (HBA)* – High Beam Assist is designed to automatically adjust the headlight range by switching between high and low beams based on light detected from other vehicles and road conditions.

To enable HBA, toggle the light switch to the AUTO Light position and turn on the high beams by pushing the lever away from you. The High Beam Assist indicator  will illuminate.



-  AUTO Automatic Headlights / High Beam Assist (HBA)* position
-  Headlight position
-  Parking Light position
-  OFF OFF position

REMINDERS:

- HBA will operate when vehicle speed exceeds 25 mph
- If the lever is pushed away from you while HBA is operational, HBA will turn off and the high beams will be on continuously. If the lever is pulled toward you while HBA is operational, HBA will turn off
- If the light switch is switched to the headlight position, HBA will turn off and low beams will be on continuously
- When the warning pop-up illuminates on the instrument cluster, the HBA is not working properly. See an authorized Kia dealer for service
- High Beam Assist does not operate below certain speeds, or in some lighting and driving conditions. Please be aware of your surroundings and exercise proper road etiquette when operating a vehicle using the high beams

Turn Signals & Fog Lights*


To operate:

- Turn Signals - Move lever Up/Down for Right/Left Turn Signal
- Fog Lights - Press switch up/down to turn Fog Lights ON/OFF

One-Touch Lane Change Signal is activated by briefly pressing the Turn Signal Lever up/down slightly up or down for less than 1 second and then releasing. The lane change signal will blink 3 times.

To change how many times the Lane Change Signal blinks (3/5/7), go to User Settings Mode* in the LCD Instrument Cluster modes (Type B cluster).

REMEMBER: Headlights must be ON for Fog Light operation.



For illustrative purposes only. Your actual display, buttons and/or features may vary. Refer to section 4 in the Owner's Manual for more information.

Smart Cruise Control (SCC)*†6,21

Smart Cruise Control is designed to maintain a predetermined distance from vehicles it detects detected ahead by automatically adjusting the driving speed as needed. When traffic is detected, the vehicle will automatically slow to maintain a set distance behind traffic without depressing the accelerator or brake pedal.

To set/adjust the SCC speed:

- Push the Driving Assist  button **A** to turn system ON. The CRUISE indicator will illuminate on the instrument cluster
- Press the SET- button **B** to set the speed. Press the RES+/SET- button **B** up/down to increase/decrease the set speed

To set the vehicle distance:

Press the Vehicle Distance button **C** on the steering wheel. The images on the LCD screen **D** in the Instrument Cluster will change when scrolling through the settings. Each time the button is pressed, the vehicle distance changes **E**.

To cancel SCC operation:


Press the CANCEL button **F** or press the brake pedal.

To turn SCC OFF: Press the Driving Assist  button **A**. The CRUISE indicator on the instrument cluster will turn OFF.


To adjust the sensitivity of SCC: Press the mode button on the Steering Wheel **G**. With the OK button **H**,

QUICK TIPS

- To change the Cruise Control mode from SCC to standard Cruise Control, press and hold button **A**. Repeat to switch modes again (SCC must not be activated to change modes)
- For the SCC System to operate, the vehicle must be traveling at a minimum speed of 5 mph
- When following a vehicle, the system will automatically adjust your cruise speed based on the vehicle detected in front. It may bring the vehicle to a complete stop if necessary. If the vehicle stops for more than 3 seconds, the system will disable



(Buttons located on right side on Steering Wheel)



The distance settings are approximations and may vary depending vehicle speed at the time. See owner's manual for more information

QR CODE

Smart Cruise Control Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

REMINDERS:

- SCC only operates at speeds above 6 mph
- SCC is activated when ignition is turned on. Speed will need to be reset when ignition is cycled ON
- In standard Cruise Control, the driver needs to manually assess the distance from other vehicles as the system will not apply brakes to slow down automatically in order to turn SCC ON/OFF
- SCC is also canceled when the driver's door is opened, gear shift is changed out of D (Drive) and various other conditions. See Owner's Manual for other conditions
- If the SCC system is left on, it can be activated inadvertently. Keep the system off when not in use to avoid setting a speed which the driver is not aware of


Images are for illustrative purposes only and may vary on actual vehicle.

SCC is a supplemental system and is not a substitute for safe driving. It is the responsibility of the driver to always check the speed and distance to the vehicle ahead.

Refer to section 5 in the Owner's Manual for more information.

Cruise Control (CC)*†‡

- A Driving Assist**  **button:** Press to turn the Cruise Control on/off
- B RES+**: Press to resume preset speed or increase Cruising Speed
- C SET-**: Press to set or decrease Cruising Speed
- D CANCEL button:** To cancel Cruise Control, do one of the following:
 - Press the brake pedal
 - Press the CANCEL button



QUICK TIPS

- Cruise Control is designed to function above 25 mph
- Cruise Control will not activate until the brake pedal has been depressed at least once after ignition ON or engine starting


REMINDER: Standard Cruise Control is a part of Smart Cruise Control and can be set as the operating mode. To switch from SCC to Standard Cruise Control, press and hold the Driving Assist button (SCC must not be activated to change modes). Repeat to switch back to SCC mode.

Your vehicle's steering wheel buttons may differ from those in the illustrations. Refer to section 5 in the Owner's Manual for more information.

Windshield Wipers & Washers

To operate:

- Move lever Up/Down to change Wiper modes
- Press button **E** to adjust intermittent wipe
- Pull lever to spray and wipe



QUICK TIPS

- Moving lever to HI increases intermittent wipe frequency and wipe speed
- Moving lever to LO decreases frequency of wipes
- Set the wiper to OFF position when the wiper is not in use

Refer to section 4 in the Owner's Manual for more information

Rear Wiper & Washer*


To operate:

- Rotate Rear Wiper switch to change Wiper modes
- Push lever to spray and wipe


QUICK TIP

On Rear Wipers, intermittent wipe function is not adjustable.

Refer to section 4 in the Owner's Manual for more information



Bluetooth® Wireless Technology†5,21



(Buttons located on left side on Steering Wheel)

REMINDER: Microphone is located in the overhead console

QUICK TIPS

- When using the voice command feature, wait for the system BEEP before speaking the command
- Phone book transfer upload time varies by phone model and with number of phone book entries
- Because of differences in phone quality, service providers and Bluetooth® Wireless Technology chip programming, functionality may differ from one phone to another

Your vehicle's steering wheel buttons may differ from those in the illustration.

For more information, refer to the Car Infotainment System Quick Reference Guide.

For Bluetooth® Wireless Technology FAQs, go to kia.com, Owners section, or call Consumer Information for Bluetooth® Technology at (800) 333-4KIA.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

- A Volume buttons:** Press \uparrow VOL / \downarrow VOL to raise/lower speaker volume
- Mute audio:** To mute the audio system, hold the  button
- B Talk button:** Press to activate voice recognition*; press and hold to exit voice recognition*
- C Receive/Place Call button*:** Press to receive/place calls. If no phone is paired, press button to pair a phone
- D End Call button:** Press to end a call, reject an incoming call or cancel a function

Pairing a Phone

For instructions on how to pair a phone, refer to the audio system's user's guide, your vehicle's Quick Start Guide or the Car Multimedia System User's Manual.

QUICK TIP

During the pairing process, be sure to accept the connection requests on the phone for phone book download and to allow acceptance of all future Bluetooth® connection requests.

How to Place a Call

When using the voice command* feature, wait for the system BEEP before speaking the command.

There are two options for placing a call:

- Option 1: Press the Receive/Place Call button **C** (displays the call history screen)
- Option 2*: Press the Talk button **B**. Then say the command "Call {name}" or Dial {number} followed by contact name or number

QR CODE

Voice Recognition Tips Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

Bluetooth® Wireless Technology^{†5,21} (continued)

Voice Recognition* and Phone Contact Tips


The system may have difficulty understanding some accents or uncommon names. Improve the performance by making a few simple changes to your phone contacts, listed below. To help optimize the *Bluetooth*® Wireless Technology Voice Recognition system, see other tips and reminders under Quick Tips:

- Use full names (first and last names) vs. short or single-syllable names (“John Smith” vs. “Dad,” “Smith Residence” vs. “Home”)
- Avoid using special characters, emojis or hyphenated names (@, &, #, /, -, *, +, etc.)
- Avoid using acronyms (“In Case of Emergency” vs. “ICE”) or words with all capital letters
- Spell words completely, no abbreviations (“Doctor Smith” vs. “Dr. Smith”)

QUICK TIPS

- The system may register or pair multiple *Bluetooth*® devices. See the Car Multimedia System User’s Manual for more information on setup and limitations
- *Bluetooth*® Music Streaming: If the *Bluetooth*® music is inaudible or too low, turn up the volume on the connected phone
- When placing a call, speak in a natural, moderate tone, with clear pronunciation. The system may have trouble recognizing commands if you speak too softly or too loudly
- Always wait for the beep before speaking any commands
- Close windows and sunroof and turn off A/C to reduce interference with the Voice Recognition
- Press the talk button and say “Help” to get a list of available commands

Audio Controls^{†21}



A Audio MODE button: Press to cycle through FM/AM/SiriusXM®*/Media modes

Audio System ON/OFF: Press to turn power on; Press and hold to turn power off; Press and hold to go to Advanced Setting / Steering Wheel mode (UVO link with Navigation)

B Seek/Preset buttons

FM/AM/SiriusXM® Modes: Press \wedge \vee to advance through Preset Stations. Press and hold to Auto Seek

Media Mode: Press to move track up/down. Press & hold to fast forward/rewind (except for *Bluetooth*® Audio)

C Volume button: Press up/down to raise/lower volume

Mute audio: Press to mute all audio (Media pauses in some Media modes when pressed)

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

Your vehicle’s steering wheel buttons may differ from those in the illustrations. Refer to section 4 in the Owner’s Manual for more information.

For other audio system information, refer to pages 32-36.

Android Auto™†3 / Apple CarPlay® Setup†4

Android Auto™*

Setting up Android Auto™:

1. From an Android Auto™ compatible device, download the Android Auto™ app from the Google Play™ Store†10
2. Open the Android Auto™ app and proceed with the onscreen instructions to complete setup on the mobile device


How to start Android Auto™:

1. Press the SETUP key on your audio system's control panel
2. Press the Device Connections button , select Android Auto™, then select ENABLE ANDROID AUTO. Review all terms, conditions and requests on the head unit and phone, and, if you agree, accept them in order to use Android Auto™
3. Connect the Android™ device with the vehicle's USB port using the manufacturer's cable provided with your phone
4. From the vehicle's Kia home screen, select the Android Auto™ button, where you'll see all the Android Auto™ supported apps

Apple CarPlay®*

Setting up and starting Apple CarPlay®:

1. On the head unit, press the SETUP key.
2. Press the Device Connections button , select Apple CarPlay® then select ENABLE APPLE CARPLAY. Review all terms, conditions and requests on the head unit and phone, and, if you agree, accept them in order to use Apple CarPlay®)
3. Connect the Apple CarPlay® compatible iPhone® with the vehicle's USB port using the manufacturer's cable provided with your iPhone®
4. From the vehicle's home screen, select the Apple CarPlay® button, where you'll see all the Apple CarPlay® supported apps



QUICK TIPS


- Android Auto™ / Apple CarPlay® Randomly Disconnects:
 - Ensure the USB cable is certified by the phone manufacturer for both power and data
 - Clean the phone's port, which the USB cable connects to, with disposable compressed air
 - The Phone should not be disturbed while driving as this can cause a disconnection at the phone's USB port
 - Visit the phone manufacturer's website for Android Auto™ / Apple CarPlay® app concerns

REMINDERS:

- Android Auto™ compatibility requirements: Micro-USB cable that came with your phone, OS Android™ 5.0 or higher, compatible Android™ smartphone and data and wireless plan for applicable feature(s)
- Apple CarPlay® compatibility requirements: Apple Lightning cable, latest iOS software, iPhone® 5 or later and data and wireless plan for applicable feature(s)
- It is recommended to always update your phone to the latest operating system release
- Ensure Apple CarPlay and Siri are enabled in your iPhone settings

For other audio system information, refer to pages 31-36. For more information, refer to the Car Infotainment System Quick Reference Guide.

Standard Audio System* – FM/AM/Media (USB, Bluetooth®†5 Audio, My Music)



Audio System Setup Options – Press the SETUP key, then using the touchscreen, press the menu item to enter (Display, Sound, Clock/Calendar, Phone, System Info). Adjust the available settings for each equipped audio system setup option by pressing the onscreen buttons/arrows. Audio system setup options may include the following:

- **Display settings** – Adjusting the Brightness, Mode Popup, MP3 Information Display
- **Sound settings** – Sound Settings, Speed Dependent Volume Control, Voice Recognition Volume, Touchscreen Beep
- **Clock/Calendar settings** – Clock Settings, Time Format, Calendar Settings, Clock Display
- **System settings** – Memory Information, Prompt Feedback, Language

Custom Key ☆: A programmable key to provide quick access to one of several available system features

To Program the Custom Key: Press and hold the Custom key. Select one of the available features you would like the Custom key to open

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

Sound Settings – To adjust the Standard Audio Systems sound settings:

1. Press the SETUP key on the audio control unit or the onscreen MENU button, when in MEDIA mode
2. Select the onscreen SOUND button
3. Select the menu item (Position, Volume, Tone, Priority, Advanced)
4. Using the touchscreen, press arrows to adjust the settings

QUICK TIPS

- Volume level between different audio modes:
 - When switching between audio modes (AM, FM, Bluetooth® Audio, etc.), the audio system saves the previous volume level you were listening to. For example, if you were listening to FM radio at volume level 20 then switched to BT Audio and adjusted the volume level to 30, the volume level will be at 20 when you switch back to FM radio
 - When using Bluetooth® Audio, the overall volume is dependent on your device's volume. If the volume is turned down low on your device it will remain low even if the system volume is turned up
- When connected to Android Auto™ or Apple CarPlay® on your smartphone, the smartphone's navigation system may also be available
- A warning screen may appear periodically to remind users that the audio system should be operated when the engine is running to prevent battery discharge
- Prolonged use of the audio control unit in ACC mode may drain the vehicle's battery

QR CODE

Standard Audio System Video

To view a video on your mobile device, snap this QR Code or visit the listed website. Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

UVO link Activation*†1

Follow these steps to activate your UVO link system:

1. Enter the activation screen on your vehicle's head unit:
 - a. Press SETUP key
 - b. Press UVO icon
 - c. Press Activate UVO
2. Read and agree to Terms of Service and Privacy Policy and press SUBMIT
3. Enter smartphone number or email address to receive a verification code, then press SUBMIT
- 4a. Follow these steps to receive your verification code using your phone SMS or email:
 - a. Check your phone SMS or email for verification code
 - b. Open the link in your SMS or email. A page will open requesting that you create your account

REMINDER: This vehicle is not equipped with over-the-air system updates.

For further UVO link operations, refer to the Car Infotainment System Quick Reference Guide. For other audio system information, refer to pages 31-36.

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.

UVO Assistance*†1



- Virtual Assistant ⓘ **A** – Press to connect to the UVO Center to hear information about the UVO features
- UVO Voice Local Search **UVO** **B** – Press to connect to the search function to find points of interest or other locations, like “cafe”
- Roadside Assist ⚠️ **C** – Press to connect to the UVO Center where you can request vehicle towing services

REMINDER: These buttons may be located in the rearview mirror or the overhead console.

For more information, refer to the Car Infotainment System Quick Reference Guide. On certain models, UVO Assistance buttons are located on the Rearview Mirror.

Note: If you already have a Kia Owners Portal account using the phone number as your login ID, you will need to provide your password prior to receiving the verification code

- c. Enter your first name, last name, email, phone number, an account password, and click CREATE ACCOUNT. A page will open displaying your verification code
- d. Enter the code in the head unit and press ACTIVATE
- e. Go back to the page with your verification code and press “I have entered my PIN.” A link will be provided to download the Kia Access with UVO link app from your app store. After installing the app, log in and enjoy




(Buttons on rearview mirror*)

Kia Access with UVO link App Download

Go to an app marketplace to download the new Kia Access with UVO link App. Once you download, make sure you register your vehicle and start an account (refer to UVO link Activation page). Get to know your new Kia and the available convenient features on the app. Below are some of the features:

- Remote Vehicle Start
- Remote Climate Control
- Locking / Unlocking Door
- Find My Car
- Schedule Charge (EV Vehicles)
- Vehicle Health Info
- Preferred Dealer Settings
- Schedule Maintenance Appointment




Kia Access with UVO link App Features Guide

The Kia Access with UVO link App Features Guide is a step-by-guide helping you utilize the app to its full potential by detailing how to set up and use each feature and adjust various settings. Below are some of the topics included:

- Remote Commands
- Set Climate
- Schedule Climate
- Schedule Charge
- Schedule Service
- Dealer Settings
- Manage Vehicles and Profiles

For further UVO link operations, refer to the Car Infotainment System Quick Reference Guide.



Kia App Screen for illustrative purposes only. Actual App screen and functionality may vary.

QR CODES

Download the **Kia Access with UVO link App** by clicking this dynamic QR code. Some phone's operating systems may need to be updated to scan dynamic QR codes.



Click this dynamic QR code to access the **Kia Access with UVO link App Features Guide**. Some phone's operating systems may need to be updated to scan dynamic QR codes



UVO link^{*†1} with Navigation^{*†13} – FM/AM/SiriusXM^{®†19}/Media (USB, Bluetooth^{®†5} Audio)


Press briefly to do the following:

- **FM/AM mode:** Play the previous/next frequency
- **SiriusXM[®] mode:** Change the channel
- **MEDIA mode:** Change the track, file or title

Press and hold to do the following (over 0.8 seconds):

- **FM/AM mode:** Move quickly through all of the frequencies. When released, the system seeks the next available frequency
- **MEDIA mode:** Rewinds or fast forwards the track or file (except for Bluetooth[®] Audio)

Press knob to turn POWER ON/OFF.
Rotate knob to adjust Volume Up/Down



Press to select FM/AM/SiriusXM[®] modes

Press to select MEDIA mode

Press to display the SETUP mode

Rotate to change Radio/SiriusXM[®] Stations/Media tracks/files

A programmable key to provide quick access to one of several available system features

Press to display the Navigation menu screen

Press to display the Map screen for the current position/VOICE mode

Sound Settings: To adjust the audio control unit's sound settings:

1. Press the SETUP key on the audio control unit or the onscreen SETUP button in ALL MENU
2. Select the onscreen SOUND button, or SOUND SETTINGS
3. Select the menu item (Position, Volume, Tone, Priority, Navigation Volume, Advanced, Reset)
4. Use the onscreen buttons to adjust settings; press the return button **⇒** to save settings

Radio Presets: You can listen to FM, AM and SiriusXM[®] radio and save frequently used stations

How to Save a Preset: Press and hold the desired slot. This saves the current station in the selected slot

SiriusXM[®] Smart Favorites: For the first ten favorite SiriusXM[®] channels, you may play live or repeat from the beginning of a song or a program segment. In Radio mode, choose SiriusXM[®], then select any of the first six favorites. During song or program play, tap the Skip Backward icon to start from the beginning of the song or program. Tap the Play Live icon to return to the live broadcast

Custom Key ☆: A programmable key to provide quick access to one of several available system features

To Program the Custom Key: Press and hold the Custom key ☆. Select one of the available features you would like the Custom key to open

REMINDER: To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

Your vehicle's audio system may differ from that in the illustration. For more information, refer to the Car Multimedia System User's Manual. For other audio system operations, refer to pages 31-35.

QR CODE

UVO link with Navigation Videos

To view a video on your mobile device, snap this QR Code or visit the listed website. Refer to the inside cover for more information.





www.youtube.com/KiaFeatureVideos

QUICK TIPS

- Volume level between different audio modes:
 - When switching between audio modes (AM, FM, Bluetooth[®] Audio, etc.), the audio system saves the previous volume level you were listening to. For example, if you were listening to FM radio at volume level 20 then switched to BT Audio and adjusted the volume level to 30, the volume level will be at 20 when you switch back to FM radio
 - When using Bluetooth[®] Audio, the overall volume is dependent on your device's volume. If the volume is turned down low on your device it will remain low even if the system volume is turned up
- At any time, you can interrupt the Command Feedback by pressing the TALK button on the steering wheel
- Prolonged use of the audio system in ACC mode may drain the vehicle's battery.
- A warning screen may appear periodically to remind users that the audio system should be operated when the engine is running to prevent battery discharge

Power Adjustable Driver's Seat*†16

Move/Press controls to adjust Seat forward/backward, Seat Cushion height, Seatback recline or Lumbar forward/backward.




REMINDER: Do not attempt to adjust the seat while the vehicle is moving. This could result in loss of control of the vehicle.

Refer to section 3 in the Owner's Manual for more information.

Seat Warmers*†18

Press button once for high setting (2 LEDs lit). Press button again for low setting (1 LED lit). Press a third time to turn OFF.



Images are for illustrative purposes only. Actual feature may vary.

QUICK TIPS

- System is OFF by default. To turn system ON, press the seat warmer switch
- With the seat warmer switch in the ON position, the heating system in the seat turns off or on automatically depending on the seat temperature

REMINDER: Use extreme caution when using the seat warmers to avoid burns. Refer to the Owner's Manual for more information.

Refer to section 3 in the Owner's Manual for more information.


6-Way Manual Adjustable Driver's Seat^{*†16}

Pull lever **A** to slide Seat forward/backward.

Pull lever **B** up several times to raise Seat Height.

Push lever **B** down several times to lower Seat Height.

Pull lever **C** to adjust Seatback Recline.



QUICK TIP

When adjusting seat forward or backward, ensure seat clicks or locks into place before driving the vehicle


REMINDER: Do not attempt to adjust the seat while the vehicle is moving. This could result in loss of control of the vehicle.

Refer to section 3 in the Owner's Manual for more information.

Front Seat Headrest Adjustment^{†9}

To raise headrest: Pull headrest up.

To lower headrest: Press lock release **D**, then press the headrest down.



QUICK TIP

For easy adjustments, hold a headrest post with one hand while using the other hand to pull the headrest from underneath


REMINDEES:

- The headrest only moves up and down as described above. It does not adjust forward or backward
- Do not operate the vehicle with the headrests removed. Headrests can provide critical neck and head support in an accident

Refer to section 3 in the Owner's Manual for more information.

Unfastening Center Seat Belt

1. If Seat Belt is buckled, press the release button on the buckle
2. To retract the 2nd-Row Center Seatbelt **A** into the headliner, press the “release button” on the buckle by inserting the seat belt tongue plate **B** in the small slot on the center buckle **C**



Refer to section 3 in the Owner's Manual for more information.

Folding Rear Seats⁺¹⁶


To Fold:

1. Adjust the Front Seatback to the upright position and/or slide the Front Seat forward
2. Insert the rear seat belt buckle into the pocket* between the Rear Seatback and Seat Cushion **D**. Insert the rear seat belt strap into the guide on the side panel next to the Seatback
3. Lower the Rear Headrests to the lowest position
4. Pull on the Rear Seatback folding lever **E**, then fold the seat towards the front

REMINDER: When you return the seatback to its upright position, always be sure it has locked into position by pushing on the top of the seatback.

To Unfold:


1. Lift and pull the Seatback backward by pulling on the folding lever **E**. Pull the Seatback firmly until it clicks and is locked into place
2. Return the rear seat belt to the proper position



QUICK TIP

It may be necessary to remove the headrests and/or adjust the front seatbacks to fully lower rear seats.

Refer to section 3 in the Owner's Manual for more information.



QR CODE

Unfastening Center Seat Belt Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos


Map/Room Lamps

Map/Room Lamp Operation: Push the lens **A** to turn the Map Lamp ON/OFF. This light produces a spot beam for convenient use as a map lamp or personal lamp for the driver or front passenger.

Door Mode: When the door button **B** is pressed, the Map Lamp turns ON when any door is opened.

Front/Rear Room Lamps: When the room button **C** is pressed, the Map and Room Lamps turn ON.

Automatic turn off function*: The interior lights automatically turn off approximately 30 seconds after the Engine System Start/Stop button* is OFF.



(Type B)


Refer to section 4 in the Owner's Manual for more information.

QUICK TIPS

- When doors are unlocked by the Smart Key*, the lamp turns ON for approximately 30 seconds
- If your vehicle is equipped with the theft alarm system, the interior lights automatically turn off approximately 3 seconds after the system is in armed stage
- Using interior lights for an extended period of time may cause battery discharge

Sunvisor^{†22}

Use the Sunvisor to shield direct light through the front or side windows. Slide the Sunvisor out and adjust as needed.



REMINDERS:

- Sunvisor may not shield all direct light
- The Sunvisor may impair visibility if not adjusted properly. Do not operate the vehicle if Sunvisor is impairing your visibility
- Be aware of seating position when adjusting or swinging Sunvisor around to or from the front or side windows
- Do not operate the vehicle if Sunvisor is impairing your visibility

Refer to section 4 in the Owner's Manual for more information.

Smart Key*

Smart Key Fob:

- A** Press to lock All Doors; Press twice within 2 seconds to sound the horn
- B** Press to unlock Driver's Door. Press twice in 4 seconds to unlock All Doors
- C** Press and hold for more than 1 second to unlock Liftgate. Then lift by the handle to **manually** open Liftgate

REMINDER: The Liftgate unlocks when the Smart Key fob is within close proximity of the rear liftgate.

- D** Press and hold more than 1 second for Panic Alarm. To turn off Alarm, press any button
- E** Press to release Mechanical Key
- F Remote Start Button*:** Press for more than two (2) seconds within four (4) seconds after locking doors to start the vehicle. Press once to turn off

REMINDER: If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the Engine Start/Stop button (Lock button side closest) and press to start engine

Driver's Door Lock/Unlock button **G**:



- Press button once to unlock driver's door
- Press again within 4 seconds to unlock all doors
- Press again to lock all doors

Mechanical Key **H**:

Use to unlock/lock Driver's Door

1. Remove door handle keyhole cover with Mechanical Key by pressing up into slot as shown **I**
2. Insert Mechanical Key **H** and turn right to Unlock Driver's Door. Turn twice within 4 seconds to Unlock all doors
3. Insert Mechanical Key and turn left to Lock Driver's Door
4. Return keyhole cover to its original position

Use to lock and unlock the glove box



QUICK TIPS

- The Smart Key's signal can be blocked by the normal operation of a cellphone or smartphone. To help prevent this, store each device separately
- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the Engine Start/Stop button (Lock button side closest) and press to start engine
- When reinserting the mechanical key into the fob, make sure it is pushed all the way in until there is a click sound

QR CODE

To view videos on your mobile device, snap these QR Codes or visit the listed website. Refer to the inside cover for more information.

Engine Start/Stop Button & Smart Key Video



Kia Key Fob Video




www.youtube.com/KiaFeatureVideos

Refer to section 3 in the Owner's Manual for more information.

Remote Keyless Entry (Folding Key)*

- A** Press the release button to release the key
- B** Press to Lock All Doors
- C** Press to unlock Driver's Door. Press twice in 4 seconds to unlock All Doors and Liftgate
- D** Press and hold for more than 1 second to unlock Liftgate and **manually** open
- E** Press and hold more than 1 second for Panic Alarm. To turn OFF Alarm, press any button



REMINDERS:

- The Liftgate does not automatically open when the button **D** is pressed
- The Liftgate unlocks when the Smart Key fob is within close proximity of the rear liftgate
- Remote button configuration may vary depending on vehicle options

Refer to section 4 in the Owner's Manual for more information.


Double-Turn Lock / Unlock All

- Turn counterclockwise once to unlock Driver's Door
- Turn counterclockwise again within 4 seconds to unlock All Doors
- Turn clockwise once to Lock All Doors

Refer to section 4 in the Owner's Manual for more information.

Fuel Cap Open Warning Indicator*

Tighten for ONE CLICK to prevent Fuel Cap Open Warning Indicator  or  from illuminating.



REMINDERS:


- The Fuel Door Release Lever is located on the lower part of the driver's door sill
- It is normal operation when tightening to hear one click and then when Fuel Cap is released, it clicks back

Refer to section 4 in the Owner's Manual for more information.

Fuel Door Release Lever

Lift the **F** lever upwards to release the fuel door.

(Lever located on the driver's floor near door sill)



Refer to section 4 in the Owner's Manual for more information.

QR CODE

To view videos on your mobile device, snap these QR Codes or visit the listed website. Refer to the inside cover for more information.

One-Click Fuel Cap Video



Kia Key Fob Video



www.youtube.com/KiaFeatureVideos

Sunroof Operation with Sunshade*

The sunroof and sunshade operation is controlled through a multidirectional button/lever **A**. The ignition needs to be in the ON position to operate the Sunroof and Sunshade.

To slide the Sunshade and Sunroof:

- Open automatically: Slide the lever **A** backward to the farthest position (second detent)
- Close automatically (sunroof only): Slide the lever **A** forward to the farthest position (second detent)

Tilt the Sunroof:

- Raise: Push lever **A** upward
- Lower: Push lever **A** forward
- Auto Close: Slide the lever **A** forward

QUICK TIP

To stop the Sunroof/Sunshade at any position, push or pull the sunroof control lever in any direction (one detent).

REMINDERS:

- If open, the Sunroof will also close when the toggle button is pressed
- Sunshade needs to remain OPEN while Sunroof is open and vehicle is moving


Sunroof Open Warning*

If the Sunroof is not fully closed, the warning will chime and display on the Instrument Cluster LCD screen* **B** when:

- The ignition is turned off (Smart Key*)
- The ignition key is removed
- The driver's door is opened

Do not adjust the sunroof or sunshade while driving. This could result in loss of control of the vehicle.

ALWAYS CHECK THE OWNER'S MANUAL FOR COMPLETE OPERATING INFORMATION AND SAFETY WARNINGS.



(Type A)



For illustrative purposes only. Display may vary

QR CODE

Sunroof Operation Video

To view a video on your mobile device, snap this QR Code or visit the listed website.

Refer to the inside cover for more information.



www.youtube.com/KiaFeatureVideos

QUICK TIPS

While driving with the rear windows down or with the sunroof* in an open or partially open position, a wind buffeting or pulsation noise may be heard. This noise is a normal occurrence and can be reduced or eliminated by the following:

- If the noise occurs with one or both of the rear windows down, partially lower both front windows approximately 1 inch
- If the noise occurs with the sunroof open, slightly reduce the size of the sunroof opening

Refer to section 4 in the Owner's Manual for more information.


*IF EQUIPPED

Rear View Monitor (RVM)^{†6}


The Rear View Monitor is a supplemental system that displays the view behind the vehicle through the audio control unit screen while the vehicle is in Reverse.

The Rear View Monitor activates when the:

1. Engine Start/Stop button* is in the ON position (green light)
2. Gear Shift Lever is in the R (Reverse) position



(Rear-Camera Display)



(Rear Camera)

REMINDERS:

- Always drive carefully and use caution when backing up
- The vehicle speed needs to be slower than 9 mph for the system to operate

Rear View Monitor is not a substitute for proper and safe backing-up procedures. Rear View Monitor may not display every object behind the vehicle. Always drive safely and use caution when backing up.



For illustrative purposes only. Display may vary.

Refer to section 4 in the Owner's Manual for more information.

Hood Release Lever and Latch

Opening the Hood:

1. Located on the bottom left of the driver's panel, pull the Hood Release Lever **A** to unlatch the Hood
2. In the front of the vehicle, lift the Hood slightly, push the secondary Latch **B** inside of the Hood's center to the left, and lift the Hood



Closing the Hood:

Lower the Hood by pressing the front center of the Hood. Then, press down to securely lock in place.


REMINDERS:

- While lowering and closing, keep hands away from under the Hood
- Open the Hood only after turning the engine off, on a flat surface, with the gear shift in P (Park) position and setting the parking brake
- Make sure the hood is securely closed before driving

Refer to section 4 in the Owner's Manual for more information.

Liftgate Release Button

With Liftgate unlocked, press the Liftgate Release button **C** and pull the Liftgate lid up by the handle to open.



(Button is located underneath the Liftgate lid)


QUICK TIPS

- The Liftgate must be unlocked before it can be opened by the Liftgate Release Button
- The Liftgate unlocks automatically and then can be opened **manually** when the Smart Key* is within close proximity to the vehicle

Refer to section 4 in the Owner's Manual for more information.

Child-Protector Rear Door Locks

Located on the rear edge of the rear passenger doors, adjust switch **A** to the LOCK position to disable the inner door handles from opening the rear doors.



REMINDER: Child-Protector Rear Door Lock is located on both rear passenger door jambs.


Refer to section 4 in the Owner's Manual for more information.

Occupant Detection System (ODS)^{†14} / PASSENGER AIRBAG OFF Indicator^{†2}

ODS is designed to detect the presence and position of the front passenger and adjusts or turns off airbag deployment accordingly. Depending on the situation and type of accident, the system may:

- Deploy airbag (Adult)
- Not deploy the airbag (Unoccupied)

If the system determines that the airbag should not be deployed, the "PASSENGER AIRBAG OFF" light will illuminate.



REMINDEMS:

- For more information about the seat belts and airbags in the vehicle or the Occupant Detection System / Passenger Airbag Off Indicator, please refer to the Owner's Manual
- Do not allow an adult passenger to ride in the front seat when the Passenger Airbag Indicator is illuminated OFF because the airbag will not deploy in the event of a crash. The driver must instruct the passenger to reposition her/himself in the seat

Refer to section 4 in the Owner's Manual for more information.

Seat Belts^{†2,17}


To properly fasten your seat belts:

1. Insert the belt tongue plate **B** into the buckle **C** until it clicks
2. Position the lap portion of the belt across your lap as **LOW ON THE HIPS** as possible
D. Adjust the belt to a **SNUG FIT** by pulling up on the shoulder portion **E**

QUICK TIP

The Seat Belt warning chime operates for driver's seat only

REMINDER: For maximum protection, always wear your seat belt.



Seat Belt Retractor Locks

Retractor locks allow lap/shoulder seat belts to remain unlocked during normal vehicle operation for freedom of movement and increased comfort.

During a **STRONG STOP, SUDDEN TURN OR CERTAIN COLLISIONS**, seat belt retractors will automatically lock the belts to reduce the risk of injury.

Refer to section 3 in the Owner's Manual for more information.

(up to 60,000 miles)^A For Non-Turbo maintenance, see back cover

MAINTENANCE ITEMS - TURBO	MAINTENANCE INTERVALS (MILES)									
	6,000	12,000	18,000	24,000	30,000	36,000	42,000	48,000	54,000	60,000
Add fuel additive ^E	P	P	P	P	P	P	P	P	P	P
Rotate tires	P	P	P	P	P	P	P	P	P	P
Engine Oil & Filter	R	R	R	R	R	R	R	R	R	R
Climate control air filter	R	R	R	R	R	R	R	R	R	R
Air cleaner filter	I	I	I	R	I	I	I	R	I	I
Battery condition	I	I	I	I	I	I	I	I	I	I
Brake lines, hoses and connections	I	I	I	I	I	I	I	I	I	I
Disc brakes and pads	I	I	I	I	I	I	I	I	I	I
Vacuum hose	I	I	I	I	I	I	I	I	I	I
Steering gear rack, linkage & boots	I	I	I	I	I	I	I	I	I	I
Drive shafts and boots	I	I	I	I	I	I	I	I	I	I
Suspension ball joints and mounting bolts	I	I	I	I	I	I	I	I	I	I
Air conditioner compressor/refrigerant	I	I	I	I	I	I	I	I	I	I
Exhaust system	I	I	I	I	I	I	I	I	I	I
Intercooler, in/out hose, air intake hose	I	I	I	I	I	I	I	I	I	I
Cooling System	I	I	I	I	I	I	I	I	I	I
Fuel lines, hoses and connections	I	I	I	I	I	I	I	I	I	I
Brake fluid	I	I	I	I	R	I	I	I	I	R
Fuel tank air filter ^{†D}		I		I		I		I		I
Parking brake		I		I		I		I		I
Vapor hose, fuel filler cap and fuel tank		I		I		I		I		I
Manual/DCT Transmission Fluid (every 37,500 miles)						I				
Spark Plugs							R			
Valve clearance ^E										I
Drive belts (First 60,000 miles, then every 15,000 miles) ^F										I

QUICK TIP Check your Maintenance Schedule or schedule an appointment with a dealer using your UVO link account by logging into your Kia Access with UVO App or your account on <https://owners.kia.com/> (Vehicles equipped with UVO link only – See page 34 for setup information)

- ‡ If equipped.
- A. See the Owner's Manual for complete maintenance schedule. These are approximate estimated intervals. Refer to vehicle mileage for maintenance item schedule.
- B. And, if necessary, adjust, correct, clean or replace.
- C. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.
- D. Both the fuel filter & fuel tank air filter are generally considered to be maintenance free, depending on fuel quality being used. However, periodic inspection is recommended. If

your vehicle is having issues like fuel flow restriction, power surging, loss of power, difficulty starting, etc., replace the fuel filter immediately and consult an authorized Kia dealer for service.

- E. Inspect for excessive tappet noise and/or engine vibration and adjust if necessary.
- F. The drive belt should be replaced when cracks occur or tension is reduced excessively.

See your Owner's Manual for more details and complete maintenance information, including severe maintenance schedule. Warranty may be voided if maintenance schedule is not followed.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, of any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

Safety Features: No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive safely.

- 1. UVO link:** Purchase/lease of certain 2019 and newer Kia vehicles with UVO link includes a complimentary 1-year subscription starting from new vehicle retail sale/lease date as recorded by the dealer. After your complimentary 1-year UVO link subscription expires, continued access to the full suite of UVO link available on your Kia will require a paid subscription at the then current subscription rate or your use of certain UVO link features may immediately terminate. Use of UVO link is subject to agreement to the UVO Privacy Policy (available at <https://owners.kia.com/us/en/privacy-policy.html>) and Terms of Service (available at <https://owners.kia.com/us/en/terms-of-service.html>). UVO link is transferable to subsequent owner during the original UVO link service term. Only use UVO link when safe to do so. Kia Access with UVO link App is available from the Apple® App Store® or Google Play™. Kia Motors America, Inc. reserves the right to change or discontinue UVO link at any time without prior notification or incurring any future obligation. Message and data rates may apply. Cellular and GPS coverage is required to use most features. UVO link features may vary by model, model year, and trim level. Features, specifications, and fees are subject to change. For more on details and limitations, visit <https://owners.kia.com> or your authorized Kia dealer. Apple and App Store are registered trademarks of Apple Inc. Google and logos are trademarks of Google, LLC.
- 2. Airbags:** For maximum protection, always wear your seat belt.
- 3. Android Auto™:** Android Auto is a trademark of Google, Inc. Android™ is a registered trademark of Google, Inc. Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation.
- 4. Apple CarPlay®:** Apple® and Apple CarPlay® are trademarks of Apple, Inc., registered in the U.S. and other countries. Apple CarPlay® runs on your smartphone cellular data service. Normal data rates will apply.
- 5. Bluetooth® Wireless Technology:** The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG Inc., and any use of such marks by Kia is pursuant to license. A Bluetooth® enabled cell phone is required to use Bluetooth® wireless technology.
- 6a. Driver Assist Features – Blind-Spot Collision Warning, Lane Keeping Assist, Rear View Monitor, Forward Collision-Avoidance Assist, Smart Cruise Control, Rear Cross-Traffic Collision-Avoidance Assist:** These features are not substitutes for safe driving, and may not detect all objects surrounding vehicle. Always drive safely and use caution.
- 6b. Driver Attention Warning (DAW):** Driver Attention Warning is not a substitute for safe driving and may not detect all instances of driver fatigue or inattentive driving practices. Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.
- 7. Electronic Stability Control (ESC)/ Traction Control System (TCS)/Hill-start Assist Control (HAC):** No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive safely.
- 8. Engine Start/Stop Button with Smart Key:** Always come to a complete stop before turning the engine on or off. However, if you have an emergency while the vehicle is in motion and must turn the engine off, you can turn the engine off to the ACC position by pressing the Start/Stop button for more than 3 seconds or 3 times in succession. If the vehicle is still moving, you can restart the engine by pressing the Start/Stop button with the shift lever in Neutral (N). With the engine off, hydraulic power assist for steering and braking will be disabled and the vehicle will be more difficult to control.
- 9. Front Seat Headrest Adjustment:** Never attempt to adjust headrests when vehicle is in motion.
- 10. Google Play™ Store** is a trademark of Google, Inc. © 2020 Google Inc. All rights reserved. Google and the Google Logo are registered trademarks of Google Inc.
- 11. Head-Up Display (HUD):** Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.
- 12. iPhone®** is a registered trademark of Apple Inc. The iPhone® mobile digital device is sold separately. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation.
- 13. Navigation:** Distracted driving can result in a loss of vehicle control. When operating a vehicle, never use a vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.
- 14. Occupant Detection System (ODS):** Kia vehicles use a number of different ODS types that vary by model. Children age 12 and under should always be seated in the REAR seats.
- 15. Roadside Assist:** 24-hour Enhanced Roadside Assistance is a service plan provided by Kia Motors America, Inc. Certain limitations apply. Coverage details are available in the Kia Warranty and Consumer Information Manual. For access to Enhanced Roadside Assistance, a connected mobile phone via Bluetooth® within the cellular service coverage area is required.
- 16. Seat adjustments:** Reclining the passenger seats can reduce the effectiveness of the safety restraint system and may lead to additional injury in an accident.
- 17. Seat belts:** For maximum protection, always wear your seatbelt.
- 18. Seat warmers:** Use extreme caution when using the seat warmers to avoid burns. Refer to the Owner's Manual for more information.
- 19. SiriusXM®:** SiriusXM Satellite Radio, SiriusXM Traffic and SiriusXM Travel Link each require a subscription sold separately, or as a package, by SiriusXM Radio Inc. **If you decide to continue your service at the end of your trial subscription, the plan you choose will automatically renew and bill at then-current rates until you call 1-866-635-2349 to cancel. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com.** Other fees and taxes will apply. All fees and programming are subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. Data displays and individual product availability vary by vehicle hardware. Current information and features may not be available in all locations, or on all receivers. Weather Forecast, Current Conditions may not be available in all locations. Images above are for representative purposes only and are not real products. For actual features and images of real products, consult the vehicle manufacturer. SiriusXM is not responsible for any errors or inaccuracies in the data services or their use in the vehicle. Travel Link Stocks displays current price and daily delta of around 7,000 actively reported securities traded on the NYSE®, NASDAQ® and AMEX®. The service is delayed approximately 20 minutes. SiriusXM satellite service is available only to those at least 18 years of age in the 48 contiguous USA, DC, and Puerto Rico (with coverage limitations). SiriusXM Internet Radio service is available throughout our satellite service area and in AK and HI. © 2020 SiriusXM Radio Inc. Sirius, XM and all related marks and logos are trademarks of SiriusXM Radio Inc.
- 20. Sportmatic®** is a registered trademark of Kia Motors America.
- 21. Steering-wheel-mounted controls:** Driving while distracted is dangerous and should be avoided. Remain attentive to driving and be cautious when using steering-wheel-mounted controls while driving.
- 22. Sunvisors:** Sunvisor may not shield all direct light. Do not operate the vehicle if sunvisor is impairing your visibility.
- 23. Tilt/Telescoping Steering Wheel:** Never attempt to adjust steering wheel position when vehicle is in motion.
- 24. Tire Pressure Monitoring System (TPMS):** Even with Tire Pressure Monitoring System, check tire pressure on a regular basis.



KEY FEATURE WALKTHROUGH

Demonstrate UVO link features and functions with the customer.

- UVO link Activation* / UVO Assistance* - page 34


- Android Auto™ / Apple CarPlay® Setup - page 32

For further UVO link operations, refer to the Car Multimedia System User's Manual.




- Standard Audio System* - page 33

For more information, refer to the Car Multimedia System User's Manual.



- UVO link with Navigation* - page 36

For more information, refer to the Car Multimedia System User's Manual.






- Bluetooth® Wireless Technology - page 30

Demonstrate operation

- Cruise Control* - page 28-29

Demonstrate operation



- Multimedia USB Port, Power Outlets & USB Charger Ports - page 19

- Digital Clock - page 19

- Engine Start/Stop Button* - page 17

- Folding Rear Seats - page 39

- Sunroof Operation with Sunshade* - page 43

- Passenger Airbag Off Indicator - page 46

- Rear View Monitor (RVM)* - page 44

- Seat Warmers* - page 37

- Smart Key* - page 41

- Tire Pressure Monitoring System (TPMS) - page 5

DURING DELIVERY

- Explain first service process and schedule first service appointment
Tour Parts & Service departments, introduce staff & explain value of Kia Parts and Service
Review recommended maintenance schedule and maintenance requirements to validate warranty
Review business hours
Review the Kia 10-year/100,000-mile warranty program
Ensure 100% satisfaction with sales and delivery process and no problems with the vehicle
Confirm time and best contact number for initial dealer follow-up

*IF EQUIPPED

Sales Consultant: _____ Date: _____

Sales Manager: _____ Date: _____

Customer: _____ Date: _____



SOUL CUSTOMER DELIVERY CHECKLIST

Owner's Name: _____ VIN: _____ Mileage: _____

Dealership Name: _____ Sales Consultant: _____ Date: _____

BEFORE DELIVERY

- Test and confirm "Good Battery" using a Kia battery tester and affix Results Label
- Verify all tire pressures are to spec (see driver's door label) LF _____ LR _____ RF _____ RR _____
- Verify proper operation of Remote Keyless Entry and Smart Key lock/unlock
- Ensure floor mats are snapped into place (if applicable)
- Verify vehicle is clean (interior and exterior), in good condition and free of chips and scratches
- Ensure all key documents are in the vehicle (Owner's Manual, Warranty and Consumer Information booklet, Tire Warranty booklet and Features & Functions Guide and any Audio System User's Manual)


KEY FEATURE WALK-THROUGH

- Air Conditioning / Climate Control – pages 22-23
Demonstrate Air Flow Modes, Defog and Defrosting Windshield.

Automatic*



Manual*



- Manual Gear Shift* – page 25
Demonstrate lifting ring for reverse gear



- Windshield/Rear Wipers & Washers – page 29

To operate:


- Move lever Up/Down to change Wiper modes
- Rotate INT switch to adjust Intermittent Wipe Speed
- Pull to spray and wipe

To operate:

- Rotate Rear Wiper switch to change Wiper modes
- Push to spray and wipe



- MIST: Single wipe
- OFF: Wiper off
- INT: Intermittent wipe
- LO: Slow wipe
- HI: Fast wipe



- ON: Normal wipe
- INT: Intermittent wipe
- OFF: Wiper Off



SOUL NORMAL MAINTENANCE SCHEDULE NON-TURBO

P=Perform • R=Replace • I=Inspect^B

(up to 60,000 miles)^A

For Turbo maintenance, see page 44

MAINTENANCE INTERVALS (MILES)

MAINTENANCE ITEMS	7,500	15,000	22,500	30,000	37,500	45,000	52,500	60,000
Rotate tires, check tire pressure and tread wear (Every 7,500 miles)	P	P	P	P	P	P	P	P
Add fuel additive ^C	P	P	P	P	P	P	P	P
Engine Oil & Engine Oil Filter	R	R	R	R	R	R	R	R
Climate control air filter [†]	R	R	R	R	R	R	R	R
Air cleaner filter	I	I	I	R	I	I	I	R
Brake fluid [‡]	I	I	I	R	I	I	I	R
Brake lines, hoses and connections	I	I	I	I	I	I	I	I
Brake discs and pads	I	I	I	I	I	I	I	I
Front suspension ball joints	I	I	I	I	I	I	I	I
Steering gear rack, linkage and boots	I	I	I	I	I	I	I	I
Drive shafts and boots	I	I	I	I	I	I	I	I
Suspension mounting bolts	I	I	I	I	I	I	I	I
Air conditioning compressor / refrigerant and performance [‡]	I	I	I	I	I	I	I	I
Exhaust system	I	I	I	I	I	I	I	I
Parking brakes	I	I	I	I	I	I	I	I
Fuel lines, fuel hoses and connections	I	I	I	I	I	I	I	I
Vacuum hose	I	I	I	I	I	I	I	I
Battery Condition	I	I	I	I	I	I	I	I
Vapor hose and fuel filler cap		I		I		I		I
Fuel tank air filter [‡]		I		I		I		I
Cooling system [‡]				I		I		I
Manual transmission fluid ^{‡F}				I		I		I
Drive belts (First 60,000 miles, then every 15,000 miles) ^G								I

QUICK TIP

Check your Maintenance Schedule or schedule an appointment with a dealer using your UVO link account by logging into your Kia Access with UVO App or your account on <https://owners.Kia.com> (Vehicles equipped with UVO link only – See page 34 for setup information)

‡ If equipped.

A. See the Owner's Manual for complete maintenance schedule. These are approximate estimated intervals.

Refer to vehicle mileage for maintenance item schedule.

B. And, if necessary, adjust, correct, clean or replace.

C. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

D. Inspect water pump when replacing the drive belt.

E. Both the fuel filter & fuel tank air filter are generally considered to be maintenance free, depending on fuel quality being used. However, periodic inspection is recommended. If your vehicle is having issues like fuel flow restriction, power surging, loss of power, difficulty starting, etc., replace the fuel filter immediately and consult an authorized Kia dealer for service.

F. Manual transmission fluid should be changed anytime it has been submerged in water.

G. The drive belt should be replaced when cracks occur or tension is reduced excessively. See your Owner's Manual for more details and complete maintenance information, including severe maintenance schedule. Warranty may be voided if maintenance schedule is not followed.

© 2020 Kia Motors America, Inc. All rights reserved.
Consumer - Roadside Assistance¹¹⁵: 1-800-333-4KIA (4542)

Part Number: UG210-PS-004R1

†LEGAL DISCLAIMERS ON BACK INSIDE COVER